

Simulavr

0.1.2.5

Generated by Doxygen 1.5.6

Sun Dec 21 18:25:27 2008

Contents

1	Simulavr Internals	2
1.1	Introduction	2
2	Memory Management	2
2.1	Memory Functions	2
2.2	Memory Macros	3
3	Objects	3
3.1	AvrClass Methods	3
3.2	Derived Class Example	4
3.3	Object Referencing	7
4	Instruction Decoder	8
5	Interrupts	8
6	Virtual Devices	8
7	External Devices	8
8	Breakpoints and Watchpoints	9
9	Todo List	9
10	Deprecated List	9
11	File Index	9
11.1	File List	9
12	File Documentation	11
12.1	adc.c File Reference	11
12.1.1	Detailed Description	11
12.1.2	Function Documentation	11
12.2	avrclass.c File Reference	12

12.2.1 Detailed Description	13
12.2.2 Function Documentation	13
12.3 avrcore.c File Reference	14
12.3.1 Detailed Description	17
12.3.2 Function Documentation	17
12.3.3 Variable Documentation	24
12.4 avrerror.c File Reference	24
12.4.1 Detailed Description	24
12.4.2 Define Documentation	25
12.5 avrmalloc.c File Reference	25
12.5.1 Detailed Description	26
12.5.2 Define Documentation	26
12.5.3 Function Documentation	27
12.6 decoder.c File Reference	29
12.6.1 Detailed Description	30
12.6.2 Enumeration Type Documentation	30
12.6.3 Function Documentation	31
12.7 device.c File Reference	31
12.7.1 Detailed Description	32
12.7.2 Function Documentation	32
12.8 devsupp.c File Reference	34
12.8.1 Detailed Description	34
12.8.2 Function Documentation	34
12.9 display.c File Reference	35
12.9.1 Detailed Description	35
12.9.2 Function Documentation	35
12.10 flash.c File Reference	39
12.10.1 Detailed Description	40
12.10.2 Function Documentation	40
12.11 gdbserver.c File Reference	42
12.11.1 Detailed Description	42

12.11.2 Function Documentation	43
12.12memory.c File Reference	43
12.12.1 Detailed Description	44
12.12.2 Function Documentation	44
12.13ports.c File Reference	47
12.13.1 Detailed Description	47
12.13.2 Function Documentation	47
12.14sig.c File Reference	48
12.14.1 Detailed Description	49
12.14.2 Function Documentation	49
12.15spi.c File Reference	50
12.15.1 Detailed Description	50
12.15.2 Function Documentation	50
12.16stack.c File Reference	51
12.16.1 Detailed Description	52
12.16.2 Function Documentation	52
12.17timers.c File Reference	55
12.17.1 Detailed Description	56
12.17.2 Function Documentation	56
12.18uart.c File Reference	58
12.18.1 Detailed Description	58
12.18.2 Function Documentation	58
12.18.3 Variable Documentation	59
12.19usb.c File Reference	60
12.19.1 Detailed Description	61
12.19.2 Function Documentation	61
12.20utils.c File Reference	62
12.20.1 Detailed Description	62
12.20.2 Function Documentation	62

1 Simulavr Internals

1.1 Introduction

This chapter documents the internals of simulavr for those wishing to work with the source code to fix bugs, add features, or to just see how it all works. If you only wish to know how to use simulavr, you don't need to read this.

Internals Topics:

- [Memory Management](#)
- [Objects](#)
- [Instruction Decoder](#)
- [Interrupts](#)
- [Virtual Devices](#)
- [External Devices](#)
- [Breakpoints and Watchpoints](#)

2 Memory Management

Every program ever written has had to deal with memory management. Simulavr is no exception. For portability and to potentially aid in memory debugging, simulavr supplies it's own functions and macros for handling the allocation and releasing of memory resources.

For memory which could be used by many differing parts of the simulator, an object referencing system has been implemented (see [Objects](#)).

2.1 Memory Functions

The following functions provide wrappers for all library functions that return memory which simulavr must manage.

- [avr_malloc\(\)](#)
- [avr_malloc0\(\)](#)
- [avr_realloc\(\)](#)
- [avr_strdup\(\)](#)

- [avr_free\(\)](#)

All functions which return allocated memory will only return if the allocation was successful. If the allocation failed, an error message is issued and the program is aborted. Thus, the developer does not need write any code to check the returned value.

2.2 Memory Macros

The following C-preprocessor macro definitions are provided for convenience and should be used instead of the underlying functions. These macros relieve the programmer from having to perform manual type-casting thus making the code easier to read.

- [avr_new\(\)](#)
- [avr_new0\(\)](#)
- [avr_renew\(\)](#)

3 Objects

Simulavr uses a simple object oriented system for handling the data structure creation and destruction. Since simulavr is written in C, a class system must be manually implemented and the basis for this class system is the `AvrClass` structure. All higher level structures are ultimately based on the `AvrClass` structure.

How the `AvrClass` structure is defined is not as import as how it is used as a base or parent class structure. A concrete example of simulavr's object system will be discussed (see [Derived Class Example](#)), but before jumping into the example, the `AvrClass` method functions will be introduced.

3.1 AvrClass Methods

The following functions provide the user interfaces to the `AvrClass` structure.

- [class_new\(\)](#)
- [class_construct\(\)](#)
- [class_destroy\(\)](#)
- [class_overload_destroy\(\)](#)
- [class_ref\(\)](#)

- [class_unref\(\)](#)

All classes must provide their own creation function, `<class>_new()`. The purpose of the creation function is to:

- Allocate memory for the class's data structure.
- Call [class_overload_destroy\(\)](#) to install the class's own destroy method.
- Call the class's constructor method to fill in the data structure information.

3.2 Derived Class Example

Simulavr's inheritance mechanism is a little more complicated than that of C++, but is still relatively easy to use once it is understood. An example should make it clear how the system works.

First we need to create some objects. Assume that we need to add two new objects to simulavr, `foo` and `bar`. To keep things simple, they are both integers. Another requirement is that any time we need to access a `foo`, we'll also need to access a `bar`, but sometimes we only need a `bar` without a `foo`. Thus, we will have a class hierarchy `FooClass->BarClass->AvrClass`, or `FooClass` derives from `BarClass` which derives from `AvrClass`. To achieve this, we create the following two data structures:

```
// Define BarClass with AvrClass as parent

typedef struct _BarClass BarClass;
struct _BarClass {
    AvrClass parent;
    int    bar;
};

// Define FooClass with BarClass as parent

typedef struct _FooClass FooClass;
struct _FooClass {
    BarClass parent;
    int    foo;
};
```

Notice that in both struct definitions, the parent element is not a pointer. When you allocate memory for a `BarClass`, you automatically allocate memory for an `AvrClass` at the same time. It's important that the parent is always the first element of any derived class structure.

The trick here is that once we have a class object, we can get at any object in it's class hierarchy with a simple type-cast.

```

void func( void )
{
    int num;
    FooClass *Foo = foo_new( 12, 21 );

    // get foo from FooClass
    num = Foo->foo;

    // get bar from BarClass
    num = ((BarClass *)Foo)->bar;

    class_unref( (AvrClass *)Foo );
}

```

Although the example above works, it assumes that the programmer knows what the FooClass and BarClass structures look like. The programmer has broken the encapsulation of both FooClass and BarClass objects. To solve this problem, we need to write method functions for both classes.

Here's the methods for BarClass :

```

// BarClass allocator
BarClass *bar_new( int bar )
{
    BarClass *bc;

    bc = avr_new( BarClass, 1 );
    bar_construct( bc, bar );
    class_overload_destroy( (AvrClass *)bc, bar_destroy );

    return bc;
}

// BarClass constructor
void bar_construct( BarClass *bc, int bar )
{
    class_construct( (AvrClass *)bc );
    bc->bar = bar;
}

// BarClass destructor
void bar_destroy( void *bc )
{
    if (bc == NULL)
        return;

    class_destroy( bc );
}

// BarClass public data access methods
int bar_get_bar( BarClass *bc ) { return bc->bar; }
void bar_set_bar( BarClass *bc, int val ) { bc->bar = val; }

```

And here's the methods for FooClass :

```
// FooClass allocator
FooClass *foo_new( int foo, int bar )
{
    FooClass *fc;

    fc = avr_new( FooClass, 1 );
    foo_construct( fc, foo, bar );
    class_overload_destroy( (AvrClass *)fc, foo_destroy );

    return fc;
}

// FooClass constructor
void foo_construct( FooClass *fc, int foo, bar )
{
    bar_construct( (BarClass *)fc, bar );
    fc->foo = foo;
}

// FooClass destructor
void foo_destroy( void *fc )
{
    if (fc == NULL)
        return;

    class_destroy( fc );
}

// FooClass public data access methods

int  foo_get_foo( FooClass *fc )      { return fc->foo; }
void foo_set_foo( FooClass *fc, int val ) { fc->foo = val; }

int  foo_get_bar( FooClass *fc )
{
    return bar_get_bar( (BarClass *)fc );
}

void foo_set_bar( FooClass *fc, int val )
{
    bar_set_bar( (BarClass *)fc, val );
}
```

Take a good look at the *_new(), *_construct() and *_destroy() functions in the above examples and make sure you understand what's going on. Of particular importance is how the constructor and destructor functions are chained up along the various classes. This pattern is used extensively throughout the simulavr source code and once understood, makes some complicated concepts incredibly easy to implement.

Now that we have the method functions, we can rewrite our original example function without the broken encapsulation.

```
void func( void )
{
    int num;
```

```
FooClass *Foo = foo_new( 12, 21 );

num = foo_get_foo( Foo );
num = foo_get_bar( Foo );

class_unref( (AvrClass *)Foo );
}
```

Now that's better, but you might think that we are breaking encapsulation when we cast `Foo` to `AvrClass`. Well, in a way we are, but since *all* class objects *must* be derived from `AvrClass` either directly or indirectly, this is acceptable.

3.3 Object Referencing

You may have noticed by this point that we haven't called `avr_free()` to free the memory we allocated for our objects. We called `class_unref()` instead. This mechanism allows us to store many references to a single object without having to keep track of all of them.

The only thing we must do when we store a reference to an object in a new variable, is call `class_ref()` on the object. Then, when that stored reference is no longer needed, we simply call `class_unref()` on the object. Once the reference count reaches zero, the object's destroy method is automatically called for us. The only hard part for us is knowing when to ref and unref the object.

Here's an example from the `simulavr` code for callbacks:

```
void callback_construct( Callback *cb,
                       Callback_FP func,
                       AvrClass *data )
{
    if (cb == NULL)
        avr_error( "passed null ptr");

    class_construct( (AvrClass *)cb );

    cb->func = func;

    cb->data = data;
    class_ref( data );
}

void callback_destroy( void *cb )
{
    Callback *_cb = (Callback *)cb;

    if (cb == NULL)
        return;

    class_unref( _cb->data );

    class_destroy( cb );
}
```

```
}
```

Notice that `data` is a pointer to `AvrClass` and thus can be any class defined by `simulavr`. `CallBack` is another class which happens to store a reference to `data` and must therefore call `class_ref()` on the `data` object. When the callback is destroyed (because the reference count reached zero), the callback destroy method calls `class_unref()` on the `data` object. It is assumed that the original reference to `data` still exists when the callback is created, but may or may not exist when the callback is destroyed.

4 Instruction Decoder

Instruction decoding and processing is implemented in the `decode.c` file.

The heart of the instruction decoder is the `decode_opcode()` function.

The `decode_opcode()` function examines the given opcode to determine which instruction applies and returns a pointer to a function to handle performing the instruction's operation. If the given opcode does not map to an instruction handler, `NULL` is returned indicating an invalid instruction.

Nearly every instruction in Atmel's Instruction Set Data Sheet will have a handler function defined. Each handler will perform all the operations described in the data sheet for a given instruction. A few instructions have synonyms. For example, `CBR` is a synonym for `ANDI`.

This should all be fairly straight forward.

5 Interrupts

FIXME: empty place holder

6 Virtual Devices

FIXME: empty place holder

7 External Devices

FIXME: empty place holder

8 Breakpoints and Watchpoints

Using gdb, it is possible to set breakpoints.

Watch points are not currently implemented.

This is only an idea right now: The way breakpoints are implemented within simulavr, it would be possible at init time to read a file containing breakpoint information. Then, as breakpoints are reached, have something happen which allows the user to check the state of the program. Anyone interested in implementing this, please step forward.

9 Todo List

Global [avr_core_run](#) Should add some basic breakpoint handling here. Maybe allow continuing, and simple breakpoint management (disable, delete, set)

File [ports.c](#) Remove the pins argument and the mask field. That's handled at a higher level so is obsolete here now.

10 Deprecated List

Global [mem_get_vdevice_by_name](#)

11 File Index

11.1 File List

Here is a list of all documented files with brief descriptions:

adc.c (Module to simulate the AVR's ADC module)	11
avrclass.c (Methods to provide user interfaces to the AvrClass structure)	12
avrcore.c (Module for the core AvrCore object, which is the AVR CPU to be simulated)	14
avrerror.c (Functions for printing messages, warnings and errors)	24
avrmalloc.c (Memory Management Functions)	25
callback.c	??

decoder.c (Module for handling opcode decoding)	29
device.c (VDevice methods)	31
devsupp.c (Contains definitions for device types (i.e. at90s8515, at90s2313, etc.))	34
display.c (Interface for using display coprocesses)	35
eeprom.c	??
flash.c (Flash memory methods)	39
gdbserver.c (Provide an interface to gdb's remote serial protocol)	42
intvects.c	??
main.c	??
memory.c (Memory access functions)	43
op_names.c	??
ports.c (Module for accessing simulated I/O ports)	47
register.c	??
sig.c (Public interface to signal handlers)	48
spi.c (Module to simulate the AVR's SPI module)	50
sram.c	??
stack.c (Module for the definition of the stack)	51
storage.c	??
timers.c (Module to simulate the AVR's on-board timer/counters)	55
uart.c (Module to simulate the AVR's uart module)	58
usb.c (Module to simulate the AVR's USB module)	60
utils.c (Utility functions)	62

12 File Documentation

12.1 `adc.c` File Reference

Module to simulate the AVR's ADC module.

Functions

- `VDevice * adc_int_create` (int *addr*, char **name*, int *rel_addr*, void **data*)
- `ADCIntr_T * adc_intr_new` (int *addr*, char **name*, int *rel_addr*)
- void `adc_intr_construct` (`ADCIntr_T *adc`, int *addr*, char **name*, int *rel_addr*)
- void `adc_intr_destroy` (void **adc*)
- `VDevice * adc_create` (int *addr*, char **name*, int *rel_addr*, void **data*)
- `ADC_T * adc_new` (int *addr*, char **name*, uint8_t *uier*, int *rel_addr*)
- void `adc_construct` (`ADC_T *adc`, int *addr*, char **name*, uint8_t *uier*, int *rel_addr*)
- void `adc_destroy` (void **adc*)
- uint16_t `adc_port_rd` (uint8_t *mux*)
- void `adc_port_wr` (uint8_t *val*)

12.1.1 Detailed Description

Module to simulate the AVR's ADC module.

Definition in file [adc.c](#).

12.1.2 Function Documentation

12.1.2.1 `VDevice* adc_int_create` (int *addr*, char * *name*, int *rel_addr*, void * *data*)

Allocate a new ADC interrupt.

Definition at line 79 of file `adc.c`.

12.1.2.2 void `adc_intr_construct` (`ADCIntr_T *adc`, int *addr*, char * *name*, int *rel_addr*)

Constructor for `adc` interrupt object.

Definition at line 99 of file `adc.c`.

References `avr_error`, and `vdev_construct()`.

12.1.2.3 void adc_intr_destroy (void * adc)

Destructor for adc interrupt object.

Definition at line 138 of file adc.c.

References vdev_destroy().

12.1.2.4 VDevice* adc_create (int addr, char * name, int rel_addr, void * data)

Allocate a new ADC structure.

Definition at line 292 of file adc.c.

References avr_error.

12.1.2.5 void adc_construct (ADC_T * adc, int addr, char * name, uint8_t uier, int rel_addr)

Constructor for ADC object.

Definition at line 318 of file adc.c.

References avr_error, and vdev_construct().

12.1.2.6 void adc_destroy (void * adc)

Destructor for ADC object.

Definition at line 357 of file adc.c.

References vdev_destroy().

12.2 avrclass.c File Reference

Methods to provide user interfaces to the AvrClass structure.

Functions

- AvrClass * [class_new](#) (void)
- void [class_construct](#) (AvrClass *klass)
- void [class_destroy](#) (void *klass)
- void [class_overload_destroy](#) (AvrClass *klass, AvrClassFP_Destroy destroy)
- void [class_ref](#) (AvrClass *klass)
- void [class_unref](#) (AvrClass *klass)

12.2.1 Detailed Description

Methods to provide user interfaces to the AvrClass structure.

This module provides the basis for simulavr's object mechanism. For a detailed discussion on using simulavr's class mechanism, see the simulavr users manual. FIXME: [TRoth 2002/03/19] move the discussion here.

Definition in file [avrclass.c](#).

12.2.2 Function Documentation

12.2.2.1 AvrClass* class_new (void)

This function should never be used.

The only potential use for it as a template for derived classes. Do Not Use This Function!

Definition at line 46 of file avrclass.c.

References [avr_new](#), and [class_construct\(\)](#).

12.2.2.2 void class_construct (AvrClass * *klass*)

Initializes the AvrClass data structure.

A derived class should call this function from their own `<klass>_construct()` function. All classes should have their constructor function call their parent's constructor function.

Definition at line 61 of file avrclass.c.

References [avr_error](#), [class_destroy\(\)](#), and [class_overload_destroy\(\)](#).

Referenced by [class_new\(\)](#), [mem_construct\(\)](#), [stack_construct\(\)](#), and [vdev_construct\(\)](#).

12.2.2.3 void class_destroy (void * *klass*)

Releases resources allocated by class's `<klass>_new()` function.

This function should never be called except as the last statement of a directly derived class's destroy method. All classes should have their destroy method call their parent's destroy method.

Definition at line 78 of file avrclass.c.

References [avr_free\(\)](#).

Referenced by [avr_core_destroy\(\)](#), [class_construct\(\)](#), [mem_destroy\(\)](#), [stack_destroy\(\)](#), and [vdev_destroy\(\)](#).

12.2.2.4 void class_overload_destroy (AvrClass * *klass*, AvrClassFP_Destroy *destroy*)

Overload the default destroy method.

Derived classes will call this to replace [class_destroy\(\)](#) with their own destroy method.

Definition at line 92 of file avrclass.c.

References [avr_error](#).

Referenced by [avr_core_new\(\)](#), [class_construct\(\)](#), [flash_new\(\)](#), [hwstack_new\(\)](#), [mem_new\(\)](#), [memstack_new\(\)](#), [stack_new\(\)](#), and [vdev_new\(\)](#).

12.2.2.5 void class_ref (AvrClass * *klass*)

Increments the reference count for the class object.

The programmer must call this whenever a reference to an object is stored in more than one place.

Definition at line 106 of file avrclass.c.

References [avr_error](#).

Referenced by [mem_attach\(\)](#), and [memstack_construct\(\)](#).

12.2.2.6 void class_unref (AvrClass * *klass*)

Decrements the reference count for the class object.

When the reference count reaches zero, the class's destroy method is called on the object.

Definition at line 120 of file avrclass.c.

References [avr_error](#).

Referenced by [avr_core_destroy\(\)](#), [dlist_add\(\)](#), [dlist_delete\(\)](#), [dlist_delete_all\(\)](#), [mem_destroy\(\)](#), and [memstack_destroy\(\)](#).

12.3 avrcore.c File Reference

Module for the core AvrCore object, which is the AVR CPU to be simulated.

Defines

- #define **BREAK_OPCODE** 0x9598

Functions

- void [avr_core_dump_core](#) (AvrCore *core, FILE *f_core)
- int [avr_core_load_program](#) (AvrCore *core, char *file, int format)
- int [avr_core_load_eeprom](#) (AvrCore *core, char *file, int format)

AvrCore handling methods

- AvrCore * [avr_core_new](#) (char *dev_name)
- void [avr_core_destroy](#) (void *core)
- void [avr_core_get_sizes](#) (AvrCore *core, int *flash, int *sram, int *sram_start, int *eeprom)
- void [avr_core_attach_vdev](#) (AvrCore *core, uint16_t addr, char *name, VDevice *vdev, int flags, uint8_t reset_value, uint8_t rd_mask, uint8_t wr_mask)
- VDevice * [avr_core_get_vdev_by_name](#) (AvrCore *core, char *name)
- VDevice * [avr_core_get_vdev_by_addr](#) (AvrCore *core, int addr)
- void [avr_core_set_state](#) (AvrCore *core, StateType state)
- int [avr_core_get_state](#) (AvrCore *core)
- void [avr_core_set_sleep_mode](#) (AvrCore *core, int sleep_mode)
- int [avr_core_get_sleep_mode](#) (AvrCore *core)

Program Memory Space Access Methods

Data Memory Space Access Methods

Status Register Access Methods

- int [avr_core_sreg_get_bit](#) (AvrCore *core, int b)
- void [avr_core_sreg_set_bit](#) (AvrCore *core, int b, int v)

RAMPZ access methods

- uint8_t [avr_core_rampz_get](#) (AvrCore *core)
- void [avr_core_rampz_set](#) (AvrCore *core, uint8_t v)

Direct I/O Register Access Methods

IO Registers are mapped in memory directly after the 32 (0x20) general registers.

- void [avr_core_io_display_names](#) (AvrCore *core)
- uint8_t [avr_core_io_read](#) (AvrCore *core, int reg)
- void [avr_core_io_write](#) (AvrCore *core, int reg, uint8_t val)

Stack Methods

- uint32_t [avr_core_stack_pop](#) (AvrCore *core, int bytes)

- void [avr_core_stack_push](#) (AvrCore *core, int bytes, uint32_t val)

Program Counter Methods

- int32_t [avr_core_PC_size](#) (AvrCore *core)
- void [avr_core_PC_incr](#) (AvrCore *core, int val)

Methods for accessing CK and instruction Clocks

- uint64_t [avr_core_CK_get](#) (AvrCore *core)
- void [avr_core_CK_incr](#) (AvrCore *core)
- int [avr_core_inst_CKS_get](#) (AvrCore *core)
- void [avr_core_inst_CKS_set](#) (AvrCore *core, int val)

Interrupt Access Methods.

- IntVect * [avr_core_irq_get_pending](#) (AvrCore *core)
- void [avr_core_irq_raise](#) (AvrCore *core, unsigned int irq)
- void [avr_core_irq_clear](#) (AvrCore *core, IntVect *irq)
- void [avr_core_irq_clear_all](#) (AvrCore *core)

Break point access methods.

- void [avr_core_insert_breakpoint](#) (AvrCore *core, int pc)
- void [avr_core_remove_breakpoint](#) (AvrCore *core, int pc)
- void [avr_core_disable_breakpoints](#) (AvrCore *core)
- void [avr_core_enable_breakpoints](#) (AvrCore *core)

Program control methods

- int [avr_core_step](#) (AvrCore *core)
- void [avr_core_run](#) (AvrCore *core)
- void [avr_core_reset](#) (AvrCore *core)

Callback Handling Methods

- void [avr_core_add_ext_rd_wr](#) (AvrCore *core, int addr, PortFP_ExtRd ext_rd, PortFP_ExtWr ext_wr)
- void [avr_core_clk_cb_add](#) (AvrCore *core, Callback *cb)
- void [avr_core_async_cb_add](#) (AvrCore *core, Callback *cb)
- void [avr_core_clk_cb_exec](#) (AvrCore *core)
- void [avr_core_async_cb_exec](#) (AvrCore *core)

Variables

- int [global_debug_inst_output](#) = 0

12.3.1 Detailed Description

Module for the core AvrCore object, which is the AVR CPU to be simulated.

Definition in file [avrcore.c](#).

12.3.2 Function Documentation

12.3.2.1 AvrCore* avr_core_new (char * dev_name)

Allocate a new AvrCore object.

Definition at line 355 of file [avrcore.c](#).

References [avr_core_destroy\(\)](#), [avr_new](#), [class_overload_destroy\(\)](#), and [dev_supp_lookup_device\(\)](#).

12.3.2.2 void avr_core_destroy (void * core)

Destructor for the AvrCore class.

Not to be called directly, except by a derived class. Called via [class_unref](#).

Definition at line 539 of file [avrcore.c](#).

References [class_destroy\(\)](#), [class_unref\(\)](#), and [dlist_delete_all\(\)](#).

Referenced by [avr_core_new\(\)](#).

12.3.2.3 void avr_core_get_sizes (AvrCore * core, int * flash, int * sram, int * sram_start, int * eeprom)

Query the sizes of the 3 memory spaces: flash, sram, and eeprom.

Definition at line 562 of file [avrcore.c](#).

References [flash_get_size\(\)](#).

12.3.2.4 void avr_core_attach_vdev (AvrCore * core, uint16_t addr, char * name, VDevice * vdev, int flags, uint8_t reset_value, uint8_t rd_mask, uint8_t wr_mask)

Attach a virtual device into the Memory.

12.3.2.5 VDevice* avr_core_get_vdev_by_name (AvrCore * core, char * name)

Returns the `VDevice` with the name `name`.

12.3.2.6 `VDevice* avr_core_get_vdev_by_addr (AvrCore * core, int addr)`

Returns the `VDevice` which handles the address `addr`.

12.3.2.7 `void avr_core_set_state (AvrCore * core, StateType state)`

Sets the device's state (running, stopped, breakpoint, sleep).

12.3.2.8 `int avr_core_get_state (AvrCore * core)`

Returns the device's state (running, stopped, breakpoint, sleep).

Referenced by `avr_core_step()`.

12.3.2.9 `void avr_core_set_sleep_mode (AvrCore * core, int sleep_mode)`

Sets the device to a sleep state.

Parameters:

core Pointer to the core.

sleep_mode The BITNUMBER of the sleepstate.

12.3.2.10 `int avr_core_get_sleep_mode (AvrCore * core)`

Return the device's sleepmode.

12.3.2.11 `int avr_core_sreg_get_bit (AvrCore * core, int b)`

Get the value of bit `b` of the status register.

12.3.2.12 `void avr_core_sreg_set_bit (AvrCore * core, int b, int v)`

Set the value of bit `b` of the status register.

12.3.2.13 `uint8_t avr_core_rampz_get (AvrCore * core)`

Get the value of the rampz register.

12.3.2.14 `void avr_core_rampz_set (AvrCore * core, uint8_t v)`

Set the value of the rampz register.

12.3.2.15 void avr_core_io_display_names (AvrCore * core)

Displays all registers.

Definition at line 723 of file avrcore.c.

References [display_io_reg_name\(\)](#), and [mem_io_fetch\(\)](#).

12.3.2.16 uint8_t avr_core_io_read (AvrCore * core, int reg)

Reads the value of a register.

Parameters:

core Pointer to the core.

reg The registers address. This address is counted above the beginning of the registers memory block (0x20).

12.3.2.17 void avr_core_io_write (AvrCore * core, int reg, uint8_t val)

Writes the value of a register. See [avr_core_io_read\(\)](#) for a discussion of *reg*.

12.3.2.18 uint32_t avr_core_stack_pop (AvrCore * core, int bytes)

Pop 1-4 bytes off of the stack.

See [stack_pop\(\)](#) for more details.

12.3.2.19 void avr_core_stack_push (AvrCore * core, int bytes, uint32_t val)

Push 1-4 bytes onto the stack.

See [stack_push\(\)](#) for more details.

12.3.2.20 int32_t avr_core_PC_size (AvrCore * core)

Returns the size of the Program Counter in bytes.

Most devices have a 16-bit PC (2 bytes), but some larger ones (e.g. mega256), have a 22-bit PC (3 bytes).

12.3.2.21 void avr_core_PC_incr (AvrCore * core, int val)

Increment the Program Counter by val.

val can be either positive or negative.

If the result of the increment is outside the valid range for PC, it is adjusted to fall in the valid range. This allows addresses to wrap around the end of the insn space.

12.3.2.22 uint64_t avr_core_CK_get (AvrCore * core)

Get the current clock counter.

Referenced by avr_core_run().

12.3.2.23 void avr_core_CK_incr (AvrCore * core)

Increment the clock counter.

Referenced by avr_core_step().

12.3.2.24 int avr_core_inst_CKS_get (AvrCore * core)

Get the number of clock cycles remaining for the currently executing instruction.

12.3.2.25 void avr_core_inst_CKS_set (AvrCore * core, int val)

Set the number of clock cycles for the instruction being executed.

Referenced by avr_core_reset().

12.3.2.26 IntVect* avr_core_irq_get_pending (AvrCore * core)

Gets the first pending irq.

Definition at line 836 of file avrcore.c.

12.3.2.27 void avr_core_irq_raise (AvrCore * core, unsigned int irq)

Raises an irq by adding it's data to the irq_pending list.

Definition at line 844 of file avrcore.c.

References avr_message.

12.3.2.28 void avr_core_irq_clear (AvrCore * core, IntVect * irq)

Calls the interrupt's callback to clear the flag.

Definition at line 857 of file avrcore.c.

12.3.2.29 void avr_core_irq_clear_all (AvrCore * core)

Removes all irqs from the irq_pending list.

Referenced by avr_core_reset().

12.3.2.30 void avr_core_insert_breakpoint (AvrCore * core, int pc)

Inserts a break point.

Definition at line 874 of file avrcore.c.

References `flash_read()`, and `flash_write()`.

12.3.2.31 void avr_core_remove_breakpoint (AvrCore * core, int pc)

Removes a break point.

Definition at line 888 of file avrcore.c.

References `flash_write()`.

12.3.2.32 void avr_core_disable_breakpoints (AvrCore * core)

Disable breakpoints.

Disables all breakpoints that where set using `avr_core_insert_breakpoint()`. The breakpoints are not removed from the breakpoint list.

Definition at line 945 of file avrcore.c.

12.3.2.33 void avr_core_enable_breakpoints (AvrCore * core)

Enable breakpoints.

Enables all breakpoints that where previous disabled.

Definition at line 958 of file avrcore.c.

12.3.2.34 int avr_core_step (AvrCore * core)

Process a single program instruction, all side effects and peripheral stimuli.

Executes instructions, calls callbacks, and checks for interrupts.

Definition at line 1083 of file avrcore.c.

References `avr_core_async_cb_exec()`, `avr_core_CK_incr()`, `avr_core_clk_cb_exec()`, and `avr_core_get_state()`.

Referenced by `avr_core_run()`.

12.3.2.35 void avr_core_run (AvrCore * core)

Start the processing of instructions by the simulator.

The simulated device will run until one of the following occurs:

- The state of the core is no longer STATE_RUNNING.
- The simulator receives a SIGINT signal.
- A breakpoint is reached (currently causes core to stop running).
- A fatal internal error occurs.

Note:

When running simulavr in gdb server mode, this function is not used. The `avr_core_step()` function is called repeatedly in a loop when the continue command is issued from gdb. As such, the functionality in this loop should be kept to a minimum.

Todo

Should add some basic breakpoint handling here. Maybe allow continuing, and simple breakpoint management (disable, delete, set)

Definition at line 1140 of file avrcore.c.

References `avr_core_CK_get()`, `avr_core_reset()`, `avr_core_step()`, `avr_message`, `get_program_time()`, `signal_has_occurred()`, `signal_watch_start()`, and `signal_watch_stop()`.

12.3.2.36 void avr_core_reset (AvrCore * core)

Sets the simulated CPU back to its initial state.

Zeroes out PC, IRQ's, clock, and memory.

Definition at line 1194 of file avrcore.c.

References `avr_core_inst_CKS_set()`, `avr_core_irq_clear_all()`, `display_clock()`, and `mem_reset()`.

Referenced by `avr_core_run()`.

12.3.2.37 void avr_core_add_ext_rd_wr (AvrCore * core, int addr, PortFP_ExtRd ext_rd, PortFP_ExtWr ext_wr)

For adding external read and write callback functions.

rd and wr should come in pairs, but it is safe to add empty function via passing a NULL pointer for either function.

Parameters:

core A pointer to an AvrCore object.

port_id The ID for handling the simulavr inheritance model.

ext_rd Function for the device core to call when it needs to communicate with the external world via I/O Ports.

ext_wr Function for the device core to call when it needs to communicate with the external world via I/O Ports.

Definition at line 1234 of file avrcore.c.

References `avr_warning`, `mem_get_vdevice_by_addr()`, and `port_add_ext_rd_wr()`.

12.3.2.38 void avr_core_clk_cb_add (AvrCore * core, Callback * cb)

Add a new clock callback to list.

12.3.2.39 void avr_core_async_cb_add (AvrCore * core, Callback * cb)

Add a new asynchronous callback to list.

12.3.2.40 void avr_core_clk_cb_exec (AvrCore * core)

Run all the callbacks in the list.

If a callback returns non-zero (true), then it is done with it's job and wishes to be removed from the list.

The time argument has dual meaning. If the callback list is for the clock callbacks, time is the value of the CK clock counter. If the callback list is for the asynchronous callback, time is the number of milliseconds from some unknown, arbitrary time on the host system.

Referenced by `avr_core_step()`.

12.3.2.41 void avr_core_async_cb_exec (AvrCore * core)

Run all the asynchronous callbacks.

Referenced by `avr_core_step()`.

12.3.2.42 void avr_core_dump_core (AvrCore * core, FILE * f_core)

Dump the contents of the entire CPU core.

Parameters:

core A pointer to an AvrCore object.

f_core An open file descriptor.

Definition at line 1284 of file avrcore.c.

References `flash_dump_core()`, and `mem_dump_core()`.

12.3.2.43 int avr_core_load_program (AvrCore * core, char * file, int format)

Load a program from an input file.

Definition at line 1297 of file avrcore.c.

References `flash_load_from_file()`.

12.3.2.44 int avr_core_load_eeprom (AvrCore * core, char * file, int format)

Load a program from an input file.

Definition at line 1304 of file avrcore.c.

References `mem_get_vdevice_by_name()`.

12.3.3 Variable Documentation**12.3.3.1 int global_debug_inst_output = 0**

Flag for enabling output of instruction debug messages.

Definition at line 64 of file avrcore.c.

12.4 avrerror.c File Reference

Functions for printing messages, warnings and errors.

Defines

- #define `avr_message`(fmt, args...) `private_avr_message(__FILE__, __LINE__, fmt, ## args)`
- #define `avr_warning`(fmt, args...) `private_avr_warning(__FILE__, __LINE__, fmt, ## args)`
- #define `avr_error`(fmt, args...) `private_avr_error(__FILE__, __LINE__, fmt, ## args)`

12.4.1 Detailed Description

Functions for printing messages, warnings and errors.

This module provides output printing facilities.

Definition in file `avrerror.c`.

12.4.2 Define Documentation

12.4.2.1 #define avr_message(fmt, args...) private_avr_message(__FILE__, __LINE__, fmt, ## args)

Print an ordinary message to stdout.

Definition at line 42 of file avrerror.c.

Referenced by avr_core_irq_raise(), avr_core_run(), and decode_init_lookup_table().

12.4.2.2 #define avr_warning(fmt, args...) private_avr_warning(__FILE__, __LINE__, fmt, ## args)

Print a warning message to stderr.

Definition at line 46 of file avrerror.c.

Referenced by avr_core_add_ext_rd_wr(), display_open(), display_send_msg(), flash_load_from_file(), mem_read(), mem_write(), signal_has_occurred(), signal_watch_start(), signal_watch_stop(), vdev_add_addr(), and vdev_def_AddAddr().

12.4.2.3 #define avr_error(fmt, args...) private_avr_error(__FILE__, __LINE__, fmt, ## args)

Print an error message to stderr and terminate program.

Definition at line 50 of file avrerror.c.

Referenced by adc_construct(), adc_create(), adc_intr_construct(), avr_malloc(), avr_malloc0(), avr_realloc(), avr_strdup(), class_construct(), class_overload_destroy(), class_ref(), class_unref(), display_eeprom(), display_flash(), display_send_msg(), display_sram(), dlist_delete(), dlist_iterator(), dlist_lookup(), flash_construct(), gdb_interact(), get_program_time(), hwstack_construct(), mem_attach(), mem_construct(), mem_get_vdevice_by_name(), memstack_construct(), ocreg16_construct(), ocreg16_create(), spi_construct(), spi_intr_construct(), stack_construct(), timer0_construct(), timer16_construct(), timer16_create(), timer_int_create(), timer_intr_construct(), uart_construct(), uart_int_create(), uart_intr_construct(), usb_construct(), usb_intr_construct(), usbi_create(), and vdev_construct().

12.5 avr_malloc.c File Reference

Memory Management Functions.

Defines

- #define [avr_new](#)(type, count) ((type *) avr_malloc ((unsigned) sizeof (type) * (count)))

- #define [avr_new0](#)(type, count) ((type *) avr_malloc0 ((unsigned) sizeof (type) * (count)))
- #define [avr_renew](#)(type, mem, count) ((type *) avr_realloc (mem, (unsigned) sizeof (type) * (count)))

Functions

- void * [avr_malloc](#) (size_t size)
- void * [avr_malloc0](#) (size_t size)
- void * [avr_realloc](#) (void *ptr, size_t size)
- char * [avr_strdup](#) (const char *s)
- void [avr_free](#) (void *ptr)

12.5.1 Detailed Description

Memory Management Functions.

This module provides facilities for managing memory.

There is no need to check the returned values from any of these functions. Any memory allocation failure is considered fatal and the program is terminated.

We want to wrap all functions that allocate memory. This way we can add secret code to track memory usage and debug memory leaks if we want. Right now, I don't want to ;).

Definition in file [avr_malloc.c](#).

12.5.2 Define Documentation

12.5.2.1 #define [avr_new](#)(type, count) ((type *) avr_malloc ((unsigned) sizeof (type) * (count)))

Macro for allocating memory.

Parameters:

- type* The C type of the memory to allocate.
- count* Allocate enough memory hold count types.

This macro is just a wrapper for [avr_malloc\(\)](#) and should be used to avoid the repetitive task of casting the returned pointer.

Definition at line 57 of file [avr_malloc.c](#).

Referenced by [avr_core_new\(\)](#), [class_new\(\)](#), [flash_new\(\)](#), [hwstack_new\(\)](#), [memstack_new\(\)](#), and [stack_new\(\)](#).

12.5.2.2 #define avr_new0(type, count) ((type *) avr_malloc0 ((unsigned) sizeof (type) * (count)))

Macro for allocating memory and initializing it to zero.

Parameters:

- type* The C type of the memory to allocate.
- count* Allocate enough memory hold count types.

This macro is just a wrapper for [avr_malloc0\(\)](#) and should be used to avoid the repetitive task of casting the returned pointer.

Definition at line 67 of file avr_malloc.c.

Referenced by [decode_init_lookup_table\(\)](#), [display_send_msg\(\)](#), [hwstack_construct\(\)](#), [mem_construct\(\)](#), [mem_new\(\)](#), and [vdev_new\(\)](#).

12.5.2.3 #define avr_renew(type, mem, count) ((type *) avr_realloc (mem, (unsigned) sizeof (type) * (count)))

Macro for allocating memory.

Parameters:

- type* The C type of the memory to allocate.
- mem* Pointer to existing memory.
- count* Allocate enough memory hold count types.

This macro is just a wrapper for [avr_malloc\(\)](#) and should be used to avoid the repetitive task of casting the returned pointer.

Definition at line 78 of file avr_malloc.c.

12.5.3 Function Documentation

12.5.3.1 void* avr_malloc (size_t size)

Allocate memory and initialize to zero.

Use the [avr_new\(\)](#) macro instead of this function.

There is no need to check the returned value, since this function will terminate the program if the memory allocation fails.

No memory is allocated if passed a size of zero.

Definition at line 93 of file avr_malloc.c.

References [avr_error](#).

12.5.3.2 void* avr_malloc0 (size_t size)

Allocate memory and initialize to zero.

Use the [avr_new0\(\)](#) macro instead of this function.

There is no need to check the returned value, since this function will terminate the program if the memory allocation fails.

No memory is allocated if passed a size of zero.

Definition at line 117 of file avrmalloc.c.

References [avr_error](#).

12.5.3.3 void* avr_realloc (void * ptr, size_t size)

Wrapper for [realloc\(\)](#). x Resizes and possibly allocates more memory for an existing memory block.

Use the [avr_renew\(\)](#) macro instead of this function.

There is no need to check the returned value, since this function will terminate the program if the memory allocation fails.

No memory is allocated if passed a size of zero.

Definition at line 143 of file avrmalloc.c.

References [avr_error](#).

12.5.3.4 char* avr_strdup (const char * s)

Wrapper for [strdup\(\)](#).

Returns a copy of the passed in string. The returned copy must be free'd.

There is no need to check the returned value, since this function will terminate the program if the memory allocation fails.

It is safe to pass a NULL pointer. No memory is allocated if a NULL is passed.

Definition at line 168 of file avrmalloc.c.

References [avr_error](#).

12.5.3.5 void avr_free (void * ptr)

Free malloc'd memory.

It is safe to pass a null pointer to this function.

Definition at line 187 of file avrmalloc.c.

Referenced by [class_destroy\(\)](#), [display_send_msg\(\)](#), [hwstack_destroy\(\)](#), and [mem_](#)

destroy().

12.6 decoder.c File Reference

Module for handling opcode decoding.

Enumerations

- enum [decoder_operand_masks](#) {
 - [mask_Rd_2](#) = 0x0030,
 - [mask_Rd_3](#) = 0x0070,
 - [mask_Rd_4](#) = 0x00f0,
 - [mask_Rd_5](#) = 0x01f0,
 - [mask_Rr_3](#) = 0x0007,
 - [mask_Rr_4](#) = 0x000f,
 - [mask_Rr_5](#) = 0x020f,
 - [mask_K_8](#) = 0x0F0F,
 - [mask_K_6](#) = 0x00CF,
 - [mask_k_7](#) = 0x03F8,
 - [mask_k_12](#) = 0x0FFF,
 - [mask_k_22](#) = 0x01F1,
 - [mask_reg_bit](#) = 0x0007,
 - [mask_sreg_bit](#) = 0x0070,
 - [mask_q_displ](#) = 0x2C07,
 - [mask_A_5](#) = 0x00F8,
 - [mask_A_6](#) = 0x060F }

Functions

- int [avr_op_UNKNOWN](#) (AvrCore *core, uint16_t opcode, unsigned int arg1, unsigned int arg2)
- void [decode_init_lookup_table](#) (void)
- struct opcode_info * [decode_opcode](#) (uint16_t opcode)

Variables

- struct opcode_info * [global_opcode_lookup_table](#)

12.6.1 Detailed Description

Module for handling opcode decoding.

The heart of the instruction decoder is the [decode_opcode\(\)](#) function.

The [decode_opcode\(\)](#) function examines the given opcode to determine which instruction applies and returns a pointer to a function to handler performing the instruction's operation. If the given opcode does not map to an instruction handler, NULL is returned.

Nearly every instruction in Atmel's Instruction Set Data Sheet will have a handler function defined. Each handler will perform all the operations described in the data sheet for a given instruction. A few instructions have synonyms. For example, CBR is a synonym for ANDI.

This should all be fairly straight forward.

Definition in file [decoder.c](#).

12.6.2 Enumeration Type Documentation

12.6.2.1 enum decoder_operand_masks

Masks to help extracting information from opcodes.

Enumerator:

- mask_Rd_2* 2 bit register id (R24, R26, R28, R30)
- mask_Rd_3* 3 bit register id (R16 - R23)
- mask_Rd_4* 4 bit register id (R16 - R31)
- mask_Rd_5* 5 bit register id (R00 - R31)
- mask_Rr_3* 3 bit register id (R16 - R23)
- mask_Rr_4* 4 bit register id (R16 - R31)
- mask_Rr_5* 5 bit register id (R00 - R31)
- mask_K_8* for 8 bit constant
- mask_K_6* for 6 bit constant
- mask_k_7* for 7 bit relative address
- mask_k_12* for 12 bit relative address
- mask_k_22* for 22 bit absolute address
- mask_reg_bit* register bit select
- mask_sreg_bit* status register bit select
- mask_q_displ* address displacement (q)
- mask_A_5* 5 bit register id (R00 - R31)

mask_A_6 6 bit IO port id

Definition at line 77 of file decoder.c.

12.6.3 Function Documentation

12.6.3.1 void decode_init_lookup_table (void)

Initialize the decoder lookup table.

This is automatically called by avr_core_construct().

It is safe to call this function many times, since it will only create the table the first time it is called.

Definition at line 3869 of file decoder.c.

References avr_message, and avr_new0.

12.6.3.2 struct opcode_info* decode_opcode (uint16_t opcode) [read]

Decode an opcode into the opcode handler function.

Generates a warning and returns NULL if opcode is invalid.

Returns a pointer to the function to handle the opcode.

12.7 device.c File Reference

VDevice methods.

Functions

- VDevice * [vdev_new](#) (char *name, VDevFP_Read rd, VDevFP_Write wr, VDevFP_Reset reset, VDevFP_AddAddr add_addr)
- void [vdev_def_AddAddr](#) (VDevice *dev, int addr, char *name, int related_addr, void *data)
- void [vdev_construct](#) (VDevice *dev, VDevFP_Read rd, VDevFP_Write wr, VDevFP_Reset reset, VDevFP_AddAddr add_addr)
- void [vdev_destroy](#) (void *dev)
- uint8_t [vdev_read](#) (VDevice *dev, int addr)
- void [vdev_write](#) (VDevice *dev, int addr, uint8_t val)
- void [vdev_reset](#) (VDevice *dev)
- void [vdev_set_core](#) (VDevice *dev, AvrClass *core)
- AvrClass * [vdev_get_core](#) (VDevice *dev)
- void [vdev_add_addr](#) (VDevice *dev, int addr, char *name, int rel_addr, void *data)

12.7.1 Detailed Description

VDevice methods.

These functions are the base for all other devices mapped into the device space.

Definition in file [device.c](#).

12.7.2 Function Documentation

12.7.2.1 VDevice* vdev_new (char * name, VDevFP_Read rd, VDevFP_Write wr, VDevFP_Reset reset, VDevFP_AddAddr add_addr)

Create a new VDevice.

Definition at line 62 of file device.c.

References [avr_new0](#), [class_overload_destroy\(\)](#), [vdev_construct\(\)](#), and [vdev_destroy\(\)](#).

12.7.2.2 void vdev_def_AddAddr (VDevice * dev, int addr, char * name, int related_addr, void * data)

Default AddAddr method.

This generate a warning that the should let the developer know that the vdev needs to be updated.

Definition at line 80 of file device.c.

References [avr_warning](#).

12.7.2.3 void vdev_construct (VDevice * dev, VDevFP_Read rd, VDevFP_Write wr, VDevFP_Reset reset, VDevFP_AddAddr add_addr)

Constructor for a VDevice.

Definition at line 89 of file device.c.

References [avr_error](#), and [class_construct\(\)](#).

Referenced by [adc_construct\(\)](#), [adc_intr_construct\(\)](#), [ocreg16_construct\(\)](#), [spi_construct\(\)](#), [spi_intr_construct\(\)](#), [timer0_construct\(\)](#), [timer16_construct\(\)](#), [timer_intr_construct\(\)](#), [uart_construct\(\)](#), [uart_intr_construct\(\)](#), [usb_construct\(\)](#), [usb_intr_construct\(\)](#), and [vdev_new\(\)](#).

12.7.2.4 void vdev_destroy (void * dev)

Destructor for a VDevice.

Definition at line 105 of file device.c.

References `class_destroy()`.

Referenced by `adc_destroy()`, `adc_intr_destroy()`, `spi_destroy()`, `spi_intr_destroy()`, `timer0_destroy()`, `timer_intr_destroy()`, `uart_destroy()`, `uart_intr_destroy()`, `usb_destroy()`, `usb_intr_destroy()`, and `vdev_new()`.

12.7.2.5 `uint8_t vdev_read (VDevice * dev, int addr)`

Reads the device's value in the register at `addr`.

Definition at line 161 of file `device.c`.

Referenced by `mem_io_fetch()`, and `mem_read()`.

12.7.2.6 `void vdev_write (VDevice * dev, int addr, uint8_t val)`

Writes an value to the register at `addr`.

Definition at line 168 of file `device.c`.

Referenced by `mem_write()`.

12.7.2.7 `void vdev_reset (VDevice * dev)`

Resets a device.

Definition at line 175 of file `device.c`.

Referenced by `mem_reset()`.

12.7.2.8 `void vdev_set_core (VDevice * dev, AvrClass * core)`

Set the core field.

Definition at line 182 of file `device.c`.

12.7.2.9 `AvrClass* vdev_get_core (VDevice * dev)`

Get the core field.

12.7.2.10 `void vdev_add_addr (VDevice * dev, int addr, char * name, int rel_addr, void * data)`

Inform the vdevice that it needs to handle another address.

This is primarily used when creating the core in `dev_supp_create_core()`.

Definition at line 195 of file `device.c`.

References `avr_warning`.

12.8 devsupp.c File Reference

Contains definitions for device types (i.e. at90s8515, at90s2313, etc.).

Functions

- int `dev_supp_has_ext_io_reg` (DevSuppDefn *dev)
- int `dev_supp_get_flash_sz` (DevSuppDefn *dev)
- int `dev_supp_get_PC_sz` (DevSuppDefn *dev)
- int `dev_supp_get_stack_sz` (DevSuppDefn *dev)
- int `dev_supp_get_vtab_idx` (DevSuppDefn *dev)
- int `dev_supp_get_sram_sz` (DevSuppDefn *dev)
- int `dev_supp_get_xram_sz` (DevSuppDefn *dev)
- DevSuppDefn * `dev_supp_lookup_device` (char *dev_name)
- void `dev_supp_list_devices` (FILE *fp)
- void `dev_supp_attach_io_regs` (AvrCore *core, DevSuppDefn *dev)

12.8.1 Detailed Description

Contains definitions for device types (i.e. at90s8515, at90s2313, etc.).

This module is used to define the attributes for each device in the AVR family. A generic constructor is used to create a new AvrCore object with the proper ports, built-in peripherals, memory layout, registers, and interrupt vectors, etc.

Definition in file [devsupp.c](#).

12.8.2 Function Documentation

12.8.2.1 DevSuppDefn* dev_supp_lookup_device (char * dev_name)

Look up a device name in support list.

Returns:

An opaque pointer to DevSuppDefn or NULL if not found.

Definition at line 266 of file devsupp.c.

Referenced by `avr_core_new()`.

12.8.2.2 void dev_supp_list_devices (FILE * fp)

Print a list of supported devices to a file pointer.

Definition at line 286 of file devsupp.c.

12.9 display.c File Reference

Interface for using display coprocesses.

Enumerations

- enum { **MAX_BUF** = 1024 }

Functions

- int [display_open](#) (char *prog, int no_xterm, int flash_sz, int sram_sz, int sram_start, int eeprom_sz)
- void [display_close](#) (void)
- void [display_send_msg](#) (char *msg)
- void [display_clock](#) (int clock)
- void [display_pc](#) (int val)
- void [display_reg](#) (int reg, uint8_t val)
- void [display_io_reg](#) (int reg, uint8_t val)
- void [display_io_reg_name](#) (int reg, char *name)
- void [display_flash](#) (int addr, int len, uint16_t *vals)
- void [display_sram](#) (int addr, int len, uint8_t *vals)
- void [display_eeprom](#) (int addr, int len, uint8_t *vals)

12.9.1 Detailed Description

Interface for using display coprocesses.

Simulavr has the ability to use a coprocess to display register and memory values in near real time.

Definition in file [display.c](#).

12.9.2 Function Documentation

12.9.2.1 int [display_open](#) (char * *prog*, int *no_xterm*, int *flash_sz*, int *sram_sz*, int *sram_start*, int *eeprom_sz*)

Open a display as a coprocess.

Parameters:

- prog* The program to use as a display coprocess.
- no_xterm* If non-zero, don't run the display in an xterm.
- flash_sz* The size of the flash memory space in bytes.

- sram_sz* The size of the sram memory space in bytes.
- sram_start* The addr of the first byte of sram (usually 0x60 or 0x100).
- eeprom_sz* The size of the eeprom memory space in bytes.

Try to start up a helper program as a child process for displaying registers and memory. If the prog argument is NULL, don't start up a display.

Returns an open file descriptor of a pipe used to send data to the helper program.

Returns -1 if something failed.

Definition at line 85 of file display.c.

References avr_warning.

12.9.2.2 void display_close (void)

Close a display and send coprocess a quit message.

Definition at line 181 of file display.c.

References display_send_msg().

12.9.2.3 void display_send_msg (char * msg)

Encode the message and send to display.

Parameters:

- msg* The message string to be sent to the display process.

Encoding is the same as that used by the gdb remote protocol: '\$...#CC' where '...' is msg, CC is checksum. There is no newline termination for encoded messages.

FIXME: TRoth: This should be a private function. It is only public so that dtest.c can be kept simple. dtest.c should be changed to avoid direct use of this function. [dtest.c has served it's purpose and will be retired soon.]

Definition at line 220 of file display.c.

References avr_error, avr_free(), avr_new0, and avr_warning.

Referenced by display_clock(), display_close(), display_eeprom(), display_flash(), display_io_reg(), display_io_reg_name(), display_pc(), display_reg(), and display_sram().

12.9.2.4 void display_clock (int clock)

Update the time in the display.

Parameters:

clock The new time in number of clocks.

Definition at line 255 of file display.c.

References display_send_msg().

Referenced by avr_core_reset().

12.9.2.5 void display_pc (int val)

Update the Program Counter in the display.

Parameters:

val The new value of the program counter.

Definition at line 269 of file display.c.

References display_send_msg().

12.9.2.6 void display_reg (int reg, uint8_t val)

Update a register in the display.

Parameters:

reg The register number.

val The new value of the register.

Definition at line 284 of file display.c.

References display_send_msg().

12.9.2.7 void display_io_reg (int reg, uint8_t val)

Update an IO register in the display.

Parameters:

reg The IO register number.

val The new value of the register.

Definition at line 299 of file display.c.

References display_send_msg().

Referenced by mem_write().

12.9.2.8 void display_io_reg_name (int *reg*, char * *name*)

Specify a name for an IO register.

Parameters:

- reg* The IO register number.
- name* The symbolic name of the register.

Names of IO registers may be different from device to device.

Definition at line 316 of file display.c.

References display_send_msg().

Referenced by avr_core_io_display_names().

12.9.2.9 void display_flash (int *addr*, int *len*, uint16_t * *vals*)

Update a block of flash addresses in the display.

Parameters:

- addr* Address of beginning of the block.
- len* Length of the block (number of words).
- vals* Pointer to an array of *len* words.

The display will update each *addr* of the block to the corresponding value in the *vals* array.

Each address in the flash references a single 16-bit wide word (or opcode or instruction). Therefore, flash addresses are aligned to 16-bit boundaries. It is simplest to consider the flash an array of 16-bit values indexed by the address.

Definition at line 340 of file display.c.

References avr_error, and display_send_msg().

Referenced by flash_write().

12.9.2.10 void display_sram (int *addr*, int *len*, uint8_t * *vals*)

Update a block of sram addresses in the display.

Parameters:

- addr* Address of beginning of the block.
- len* Length of the block (number of bytes).
- vals* Pointer to an array of *len* bytes.

The display will update each *addr* of the block to the corresponding value in the *vals* array.

Definition at line 372 of file `display.c`.

References `avr_error`, and `display_send_msg()`.

12.9.2.11 void display_eeprom (int *addr*, int *len*, uint8_t * *vals*)

Update a block of eeprom addresses in the display.

Parameters:

addr Address of beginning of the block.

len Length of the block (number of bytes).

vals Pointer to an array of *len* bytes.

The display will update each *addr* of the block to the corresponding value in the *vals* array.

Definition at line 404 of file `display.c`.

References `avr_error`, and `display_send_msg()`.

12.10 flash.c File Reference

Flash memory methods.

Functions

- uint16_t `flash_read` (Flash *flash, int addr)
- void `flash_write` (Flash *flash, int addr, uint16_t val)
- void `flash_write_lo8` (Flash *flash, int addr, uint8_t val)
- void `flash_write_hi8` (Flash *flash, int addr, uint8_t val)
- Flash * `flash_new` (int size)
- void `flash_construct` (Flash *flash, int size)
- void `flash_destroy` (void *flash)
- int `flash_load_from_file` (Flash *flash, char *file, int format)
- int `flash_get_size` (Flash *flash)
- void `flash_dump_core` (Flash *flash, FILE *f_core)

12.10.1 Detailed Description

Flash memory methods.

This module provides functions for reading and writing to flash memory. Flash memory is the program (.text) memory in AVR's Harvard architecture. It is completely separate from RAM, which is simulated in the [memory.c](#) file.

Definition in file [flash.c](#).

12.10.2 Function Documentation

12.10.2.1 uint16_t flash_read (Flash **flash*, int *addr*)

Reads a 16-bit word from flash.

Returns:

A word.

Referenced by `avr_core_insert_breakpoint()`, and `flash_dump_core()`.

12.10.2.2 void flash_write (Flash **flash*, int *addr*, uint16_t *val*)

Writes a 16-bit word to flash.

Parameters:

flash A pointer to a flash object.

addr The address to which to write.

val The word to write there.

Definition at line 86 of file `flash.c`.

References `display_flash()`.

Referenced by `avr_core_insert_breakpoint()`, and `avr_core_remove_breakpoint()`.

12.10.2.3 void flash_write_lo8 (Flash **flash*, int *addr*, uint8_t *val*)

Write the low-order byte of an address.

AVRs are little-endian, so lo8 bits in odd addresses.

Definition at line 98 of file `flash.c`.

12.10.2.4 void flash_write_hi8 (Flash **flash*, int *addr*, uint8_t *val*)

Write the high-order byte of an address.

AVRs are little-endian, so hi8 bits in even addresses.

Definition at line 109 of file flash.c.

12.10.2.5 Flash* flash_new (int *size*)

Allocate a new Flash object.

Definition at line 117 of file flash.c.

References avr_new, class_overload_destroy(), flash_construct(), and flash_destroy().

12.10.2.6 void flash_construct (Flash **flash*, int *size*)

Constructor for the flash object.

Definition at line 131 of file flash.c.

References avr_error.

Referenced by flash_new().

12.10.2.7 void flash_destroy (void **flash*)

Destructor for the flash class.

Not to be called directly, except by a derived class. Called via class_unref.

Definition at line 153 of file flash.c.

Referenced by flash_new().

12.10.2.8 int flash_load_from_file (Flash **flash*, char **file*, int *format*)

Load program data into flash from a file.

Definition at line 164 of file flash.c.

References avr_warning.

Referenced by avr_core_load_program().

12.10.2.9 int flash_get_size (Flash **flash*)

Accessor method to get the size of a flash.

Definition at line 210 of file flash.c.

Referenced by avr_core_get_sizes().

12.10.2.10 void flash_dump_core (Flash **flash*, FILE **f_core*)

Dump the contents of the flash to a file descriptor in text format.

Parameters:

flash A pointer to a flash object.

f_core An open file descriptor.

Definition at line 223 of file flash.c.

References `flash_read()`.

Referenced by `avr_core_dump_core()`.

12.11 gdbserver.c File Reference

Provide an interface to gdb's remote serial protocol.

Functions

- void `gdb_interact` (GdbComm_T **comm*, int *port*, int *debug_on*)

12.11.1 Detailed Description

Provide an interface to gdb's remote serial protocol.

This module allows a program to be used by gdb as a remote target. The remote target and gdb communicate via gdb's remote serial protocol. The protocol is documented in the gdb manual and will not be repeated here.

Hitting Ctrl-c in gdb can be used to interrupt the remote target while it is processing instructions and return control back to gdb.

Issuing a 'signal SIGxxx' command from gdb will send the signal to the remote target via a "continue with signal" packet. The target will process and interpret the signal, but not pass it on to the AVR program running in the target since it really makes no sense to do so. In some circumstances, it may make sense to use the gdb signal mechanism as a way to initiate some sort of external stimulus to be passed on to the virtual hardware system.

Signals from gdb which are processed have the following meanings:

- `SIGHUP` Initiate a reset of the target. (Simulates a hardware reset)

Definition in file `gdbserver.c`.

12.11.2 Function Documentation

12.11.2.1 void gdb_interact (GdbComm_T *comm, int port, int debug_on)

Start interacting with gdb.

Parameters:

- comm* A previously initialized simulator comm
- port* Port which server will listen for connections on.
- debug_on* Turn on gdb debug diagnostic messages.

Start a tcp server socket on localhost listening for connections on the given port. Once a connection is established, enter an infinite loop and process command requests from gdb using the remote serial protocol. Only a single connection is allowed at a time.

Definition at line 1320 of file gdbserver.c.

References `avr_error`, `signal_has_occurred()`, `signal_watch_start()`, and `signal_watch_stop()`.

12.12 memory.c File Reference

Memory access functions.

Functions

- Memory * [mem_new](#) (int gpwr_end, int io_reg_end, int sram_end, int xram_end)
- void [mem_construct](#) (Memory *mem, int gpwr_end, int io_reg_end, int sram_end, int xram_end)
- void [mem_destroy](#) (void *mem)
- void [mem_attach](#) (Memory *mem, int addr, char *name, VDevice *vdev, int flags, uint8_t reset_value, uint8_t rd_mask, uint8_t wr_mask)
- VDevice * [mem_get_vdevice_by_addr](#) (Memory *mem, int addr)
- VDevice * [mem_get_vdevice_by_name](#) (Memory *mem, char *name)
- void [mem_set_addr_name](#) (Memory *mem, int addr, char *name)
- uint8_t [mem_read](#) (Memory *mem, int addr)
- void [mem_write](#) (Memory *mem, int addr, uint8_t val)
- void [mem_reset](#) (Memory *mem)
- void [mem_io_fetch](#) (Memory *mem, int addr, uint8_t *val, char *buf, int bufsiz)
- void [mem_dump_core](#) (Memory *mem, FILE *f_core)

12.12.1 Detailed Description

Memory access functions.

This module provides functions for reading and writing to simulated memory. The Memory class is a subclass of AvrClass.

Definition in file [memory.c](#).

12.12.2 Function Documentation

12.12.2.1 Memory* mem_new (int gpwr_end, int io_reg_end, int sram_end, int xram_end)

Allocates memory for a new memory object.

Definition at line 66 of file memory.c.

References [avr_new0](#), [class_overload_destroy\(\)](#), [mem_construct\(\)](#), and [mem_destroy\(\)](#).

12.12.2.2 void mem_construct (Memory * mem, int gpwr_end, int io_reg_end, int sram_end, int xram_end)

Constructor for the memory object.

Definition at line 80 of file memory.c.

References [avr_error](#), [avr_new0](#), and [class_construct\(\)](#).

Referenced by [mem_new\(\)](#).

12.12.2.3 void mem_destroy (void * mem)

Destructor for the memory object.

Definition at line 99 of file memory.c.

References [avr_free\(\)](#), [class_destroy\(\)](#), and [class_unref\(\)](#).

Referenced by [mem_new\(\)](#).

12.12.2.4 void mem_attach (Memory * mem, int addr, char * name, VDevice * vdev, int flags, uint8_t reset_value, uint8_t rd_mask, uint8_t wr_mask)

Attach a device to the device list.

Devices that are accessed more often should be attached last so that they will be at the front of the list.

A default virtual device can be overridden by attaching a new device ahead of it in the list.

Definition at line 130 of file memory.c.

References `avr_error`, and `class_ref()`.

12.12.2.5 VDevice* mem_get_vdevice_by_addr (Memory * mem, int addr)

Find the VDevice associated with the given address.

Definition at line 159 of file memory.c.

Referenced by `avr_core_add_ext_rd_wr()`, and `memstack_construct()`.

12.12.2.6 VDevice* mem_get_vdevice_by_name (Memory * mem, char * name)

Find the VDevice associated with the given name.

Deprecated

Definition at line 169 of file memory.c.

References `avr_error`, and `dlist_lookup()`.

Referenced by `avr_core_load_eeprom()`.

12.12.2.7 uint8_t mem_read (Memory * mem, int addr)

Reads byte from memory and sanity-checks for valid address.

Parameters:

mem A pointer to the memory object

addr The address to be read

Returns:

The byte found at that address *addr*

Definition at line 212 of file memory.c.

References `avr_warning`, and `vdev_read()`.

12.12.2.8 void mem_write (Memory * mem, int addr, uint8_t val)

Writes byte to memory and updates display for io registers.

Parameters:

mem A pointer to a memory object

addr The address to be written to

val The value to be written there

Definition at line 247 of file memory.c.

References avr_warning, display_io_reg(), and vdev_write().

12.12.2.9 void mem_reset (Memory * mem)

Resets every device in the memory object.

Parameters:

mem A pointer to the memory object.

Definition at line 284 of file memory.c.

References vdev_reset().

Referenced by avr_core_reset().

12.12.2.10 void mem_io_fetch (Memory * mem, int addr, uint8_t * val, char * buf, int bufsiz)

Fetch the name and value of the io register (addr).

Parameters:

mem A pointer to the memory object.

addr The address to fetch from.

val A pointer where the value of the register is to be copied.

buf A pointer to where the name of the register should be copied.

bufsiz The maximum size of the the buf string.

Definition at line 322 of file memory.c.

References vdev_read().

Referenced by avr_core_io_display_names().

12.12.2.11 void mem_dump_core (Memory * mem, FILE * f_core)

Dump all the various memory locations to a file descriptor in text format.

Parameters:

mem A memory object.

f_core An open file descriptor.

Definition at line 483 of file memory.c.

Referenced by avr_core_dump_core().

12.13 ports.c File Reference

Module for accessing simulated I/O ports.

Functions

- VDevice * [port_create](#) (int addr, char *name, int rel_addr, void *data)
- void [port_ext_disable](#) (Port *p)
- void [port_ext_enable](#) (Port *p)
- void [port_add_ext_rd_wr](#) (Port *p, PortFP_ExtRd ext_rd, PortFP_ExtWr ext_wr)

12.13.1 Detailed Description

Module for accessing simulated I/O ports.

Defines an abstract Port class as well as subclasses for each individual port.

Todo

Remove the pins argument and the mask field. That's handled at a higher level so is obsolete here now.

Definition in file [ports.c](#).

12.13.2 Function Documentation**12.13.2.1 VDevice* port_create (int addr, char * name, int rel_addr, void * data)**

Create a new Port instance.

This should only be used in DevSuppDefn initializers.

Definition at line 100 of file ports.c.

12.13.2.2 void port_ext_disable (Port *p)

Disable external port functionality.

This is only used when dumping memory to core file. See [mem_io_fetch\(\)](#).

Definition at line 200 of file ports.c.

12.13.2.3 void port_ext_enable (Port *p)

Enable external port functionality.

This is only used when dumping memory to core file. See [mem_io_fetch\(\)](#).

Definition at line 210 of file ports.c.

12.13.2.4 void port_add_ext_rd_wr (Port *p, PortFP_ExtRd ext_rd, PortFP_ExtWr ext_wr)

Attaches read and write functions to a particular port.

I think I may have this backwards. Having the virtual hardware supply functions for the core to call on every io read/write, might cause missed events (like edge triggered). I'm really not too sure how to handle this.

In the future, it might be better to have the core supply a function for the virtual hardware to call when data is written to the device. The device supplied function could then check if an interrupt should be generated or just simply write to the port data register.

For now, leave it as is since it's easier to test if you can block when the device is reading from the virtual hardware.

Definition at line 231 of file ports.c.

Referenced by [avr_core_add_ext_rd_wr\(\)](#).

12.14 sig.c File Reference

Public interface to signal handlers.

Functions

- void [signal_watch_start](#) (int signo)
- void [signal_watch_stop](#) (int signo)
- int [signal_has_occurred](#) (int signo)
- void [signal_reset](#) (int signo)

12.14.1 Detailed Description

Public interface to signal handlers.

This module provides a way for the simulator to process signals generated by the native host system. Note that these signals in this context have nothing to do with signals or interrupts as far as a program running in the simulator is concerned.

Definition in file [sig.c](#).

12.14.2 Function Documentation

12.14.2.1 void signal_watch_start (int *signo*)

Start watching for the occurrence of the given signal.

This function will install a signal handler which will set a flag when the signal occurs. Once the watch has been started, periodically call [signal_has_occurred\(\)](#) to check if the signal was raised.

Definition at line 67 of file sig.c.

References [avr_warning](#).

Referenced by [avr_core_run\(\)](#), and [gdb_interact\(\)](#).

12.14.2.2 void signal_watch_stop (int *signo*)

Stop watching signal.

Restores the default signal handler for the given signal and resets the signal flag.

Definition at line 97 of file sig.c.

References [avr_warning](#), and [signal_reset\(\)](#).

Referenced by [avr_core_run\(\)](#), and [gdb_interact\(\)](#).

12.14.2.3 int signal_has_occurred (int *signo*)

Check to see if a signal has occurred.

Returns:

Non-zero if signal has occurred. The flag will always be reset automatically.

Definition at line 119 of file sig.c.

References [avr_warning](#).

Referenced by [avr_core_run\(\)](#), [gdb_interact\(\)](#), and [signal_reset\(\)](#).

12.14.2.4 void signal_reset (int signo)

Clear the flag which indicates that a signal has occurred.

Use signal_reset to manually reset (i.e. clear) the flag.

Definition at line 142 of file sig.c.

References signal_has_occurred().

Referenced by signal_watch_stop().

12.15 spi.c File Reference

Module to simulate the AVR's SPI module.

Functions

- VDevice * [spii_create](#) (int addr, char *name, int rel_addr, void *data)
- SPIIntr_T * [spi_intr_new](#) (int addr, char *name)
- void [spi_intr_construct](#) (SPIIntr_T *spi, int addr, char *name)
- void [spi_intr_destroy](#) (void *spi)
- VDevice * [spi_create](#) (int addr, char *name, int rel_addr, void *data)
- SPI_T * [spi_new](#) (int addr, char *name, int rel_addr)
- void [spi_construct](#) (SPI_T *spi, int addr, char *name, int rel_addr)
- void [spi_destroy](#) (void *spi)
- uint8_t [spi_port_rd](#) (int addr)
- void [spi_port_wr](#) (uint8_t val)

12.15.1 Detailed Description

Module to simulate the AVR's SPI module.

Definition in file [spi.c](#).

12.15.2 Function Documentation

12.15.2.1 VDevice* spii_create (int addr, char * name, int rel_addr, void * data)

Allocate a new SPI interrupt.

Definition at line 78 of file spi.c.

12.15.2.2 void spi_intr_construct (SPIIntr_T * spi, int addr, char * name)

Constructor for spi interrupt object.

Definition at line 98 of file spi.c.

References `avr_error`, and `vdev_construct()`.

12.15.2.3 void spi_intr_destroy (void * spi)

Destructor for spi interrupt object.

Definition at line 134 of file spi.c.

References `vdev_destroy()`.

12.15.2.4 VDevice* spi_create (int addr, char * name, int rel_addr, void * data)

Allocate a new SPI structure.

Definition at line 247 of file spi.c.

12.15.2.5 void spi_construct (SPI_T * spi, int addr, char * name, int rel_addr)

Constructor for SPI object.

Definition at line 267 of file spi.c.

References `avr_error`, and `vdev_construct()`.

12.15.2.6 void spi_destroy (void * spi)

Destructor for SPI object.

Definition at line 300 of file spi.c.

References `vdev_destroy()`.

12.16 `stack.c` File Reference

Module for the definition of the stack.

Functions

- Stack * [stack_new](#) (StackFP_Pop pop, StackFP_Push push)
- void [stack_construct](#) (Stack *stack, StackFP_Pop pop, StackFP_Push push)
- void [stack_destroy](#) (void *stack)

- `uint32_t stack_pop` (`Stack *stack`, `int bytes`)
- `void stack_push` (`Stack *stack`, `int bytes`, `uint32_t val`)
- `HWStack * hwstack_new` (`int depth`)
- `void hwstack_construct` (`HWStack *stack`, `int depth`)
- `void hwstack_destroy` (`void *stack`)
- `VDevice * sp_create` (`int addr`, `char *name`, `int rel_addr`, `void *data`)
- `MemStack * memstack_new` (`Memory *mem`, `int spl_addr`)
- `void memstack_construct` (`MemStack *stack`, `Memory *mem`, `int spl_addr`)
- `void memstack_destroy` (`void *stack`)

12.16.1 Detailed Description

Module for the definition of the stack.

Defines the classes `stack`, `hw_stack`, and `mem_stack`.

FIXME: Ted, I would really really really love to put in a description of what is the difference between these three classes and how they're used, but I don't understand it myself.

Definition in file `stack.c`.

12.16.2 Function Documentation

12.16.2.1 `Stack* stack_new (StackFP_Pop pop, StackFP_Push push)`

Allocates memory for a new `Stack` object.

This is a virtual method for higher level stack implementations and as such should not be used directly.

Definition at line 82 of file `stack.c`.

References `avr_new`, `class_overload_destroy()`, `stack_construct()`, and `stack_destroy()`.

12.16.2.2 `void stack_construct (Stack *stack, StackFP_Pop pop, StackFP_Push push)`

Constructor for the `Stack` class.

This is a virtual method for higher level stack implementations and as such should not be used directly.

Definition at line 99 of file `stack.c`.

References `avr_error`, and `class_construct()`.

Referenced by `hwstack_construct()`, `memstack_construct()`, and `stack_new()`.

12.16.2.3 void stack_destroy (void * *stack*)

Destructor for the Stack class.

This is a virtual method for higher level stack implementations and as such should not be used directly.

Definition at line 116 of file stack.c.

References class_destroy().

Referenced by hwstack_destroy(), memstack_destroy(), and stack_new().

12.16.2.4 uint32_t stack_pop (Stack * *stack*, int *bytes*)

Pops a byte or a word off the stack and returns it.

Parameters:

stack A pointer to the Stack object from which to pop

bytes Number of bytes to pop off the stack (1 to 4 bytes).

Returns:

The 1 to 4 bytes value popped from the stack.

This method provides access to the derived class's pop() method.

Definition at line 133 of file stack.c.

12.16.2.5 void stack_push (Stack * *stack*, int *bytes*, uint32_t *val*)

Pushes a byte or a word of data onto the stack.

Parameters:

stack A pointer to the Stack object from which to pop.

bytes Size of the value being pushed onto the stack (1 to 4 bytes).

val The value to be pushed.

This method provides access to the derived class's push() method.

Definition at line 146 of file stack.c.

12.16.2.6 HWStack* hwstack_new (int *depth*)

Allocate a new HWStack object.

This is the stack implementation used by devices which lack SRAM and only have a fixed size hardware stack (e.i., the at90s1200)

Definition at line 163 of file `stack.c`.

References `avr_new`, `class_overload_destroy()`, `hwstack_construct()`, and `hwstack_destroy()`.

12.16.2.7 `void hwstack_construct (HWStack * stack, int depth)`

Constructor for HWStack object.

Definition at line 177 of file `stack.c`.

References `avr_error`, `avr_new0`, and `stack_construct()`.

Referenced by `hwstack_new()`.

12.16.2.8 `void hwstack_destroy (void * stack)`

Destructor for HWStack object.

Definition at line 191 of file `stack.c`.

References `avr_free()`, and `stack_destroy()`.

Referenced by `hwstack_new()`.

12.16.2.9 `VDevice* sp_create (int addr, char * name, int rel_addr, void * data)`

Create the Stack Pointer VDevice.

This should only be used in the DevSuppDefn io reg init structure.

Definition at line 272 of file `stack.c`.

12.16.2.10 `MemStack* memstack_new (Memory * mem, int spl_addr)`

Allocate a new MemStack object.

Definition at line 388 of file `stack.c`.

References `avr_new`, `class_overload_destroy()`, `memstack_construct()`, and `memstack_destroy()`.

12.16.2.11 `void memstack_construct (MemStack * stack, Memory * mem, int spl_addr)`

Constructor for MemStack object.

Definition at line 402 of file `stack.c`.

References `avr_error`, `class_ref()`, `mem_get_vdevice_by_addr()`, and `stack_construct()`.

Referenced by `memstack_new()`.

12.16.2.12 void memstack_destroy (void * stack)

Destructor for MemStack object.

Definition at line 423 of file `stack.c`.

References `class_unref()`, and `stack_destroy()`.

Referenced by `memstack_new()`.

12.17 timers.c File Reference

Module to simulate the AVR's on-board timer/counters.

Functions

- VDevice * `timer_int_create` (int addr, char *name, int rel_addr, void *data)
- TimerIntr_T * `timer_intr_new` (int addr, char *name, uint8_t func_mask)
- void `timer_intr_construct` (TimerIntr_T *ti, int addr, char *name, uint8_t func_mask)
- void `timer_intr_destroy` (void *ti)
- VDevice * `timer0_create` (int addr, char *name, int rel_addr, void *data)
- Timer0_T * `timer0_new` (int addr, char *name, int rel_addr)
- void `timer0_construct` (Timer0_T *timer, int addr, char *name, int rel_addr)
- void `timer0_destroy` (void *timer)

16 Bit Timer Functions

- VDevice * `timer16_create` (int addr, char *name, int rel_addr, void *data)
- Timer16_T * `timer16_new` (int addr, char *name, int rel_addr, Timer16Def timerdef)
- void `timer16_construct` (Timer16_T *timer, int addr, char *name, int rel_addr, Timer16Def timerdef)

16 Bit Output Compare Register Functions

- VDevice * `ocreg16_create` (int addr, char *name, int rel_addr, void *data)
- OCREg16_T * `ocreg16_new` (int addr, char *name, OCREg16Def ocrdef)
- void `ocreg16_construct` (OCReg16_T *ocreg, int addr, char *name, OCREg16Def ocrdef)

12.17.1 Detailed Description

Module to simulate the AVR's on-board timer/counters.

This currently only implements the timer/counter 0.

Definition in file [timers.c](#).

12.17.2 Function Documentation

12.17.2.1 `VDevice* timer_int_create (int addr, char * name, int rel_addr, void * data)`

Allocate a new timer interrupt.

Definition at line 138 of file `timers.c`.

References `avr_error`.

12.17.2.2 `void timer_intr_construct (TimerIntr_T * ti, int addr, char * name, uint8_t func_mask)`

Constructor for timer interrupt object.

Definition at line 163 of file `timers.c`.

References `avr_error`, and `vdev_construct()`.

12.17.2.3 `void timer_intr_destroy (void * ti)`

Destructor for timer interrupt object.

Definition at line 205 of file `timers.c`.

References `vdev_destroy()`.

12.17.2.4 `VDevice* timer0_create (int addr, char * name, int rel_addr, void * data)`

Allocate a new timer/counter 0.

Definition at line 350 of file `timers.c`.

12.17.2.5 `void timer0_construct (Timer0_T * timer, int addr, char * name, int rel_addr)`

Constructor for timer/counter 0 object.

Definition at line 370 of file `timers.c`.

References `avr_error`, and `vdev_construct()`.

12.17.2.6 void timer0_destroy (void * timer)

Destructor for timer/counter 0 object.

Definition at line 387 of file timers.c.

References vdev_destroy().

12.17.2.7 VDevice* timer16_create (int addr, char * name, int rel_addr, void * data)

Allocate a new 16 bit timer/counter.

Definition at line 582 of file timers.c.

References avr_error.

12.17.2.8 void timer16_construct (Timer16_T * timer, int addr, char * name, int rel_addr, Timer16Def timerdef)

Constructor for 16 bit timer/counter object.

Definition at line 608 of file timers.c.

References avr_error, and vdev_construct().

12.17.2.9 VDevice* ocreg16_create (int addr, char * name, int rel_addr, void * data)

Allocate a new 16 bit Output Compare Register.

Parameters:

ocrdef The definition struct for the *OCR* to be created

Definition at line 909 of file timers.c.

References avr_error.

12.17.2.10 void ocreg16_construct (OCReg16_T * ocreg, int addr, char * name, OCReg16Def ocrdef)

Constructor for 16 bit Output Compare Register object.

Definition at line 935 of file timers.c.

References avr_error, and vdev_construct().

12.18 `uart.c` File Reference

Module to simulate the AVR's uart module.

Functions

- `VDevice * uart_int_create` (int addr, char *name, int rel_addr, void *data)
- `UARTIntr_T * uart_intr_new` (int addr, char *name, void *data)
- `void uart_intr_construct` (UARTIntr_T *uart, int addr, char *name)
- `void uart_intr_destroy` (void *uart)
- `VDevice * uart_create` (int addr, char *name, int rel_addr, void *data)
- `UART_T * uart_new` (int addr, char *name, int rel_addr)
- `void uart_construct` (UART_T *uart, int addr, char *name, int rel_addr)
- `void uart_destroy` (void *uart)
- `uint16_t uart_port_rd` (int addr)
- `void uart_port_wr` (uint8_t val)

Variables

- unsigned int `UART_Int_Table` []
- unsigned int `UART0_Int_Table` []
- unsigned int `UART1_Int_Table` []

12.18.1 Detailed Description

Module to simulate the AVR's uart module.

Definition in file `uart.c`.

12.18.2 Function Documentation

12.18.2.1 `VDevice* uart_int_create` (int *addr*, char * *name*, int *rel_addr*, void * *data*)

Allocate a new uart interrupt.

Definition at line 95 of file `uart.c`.

References `avr_error`.

12.18.2.2 void `uart_intr_construct` (`UARTIntr_T * uart`, `int addr`, `char * name`)

Constructor for uart interrupt object.

Definition at line 128 of file `uart.c`.

References `avr_error`, and `vdev_construct()`.

12.18.2.3 void `uart_intr_destroy` (`void * uart`)

Destructor for uart interrupt object.

Definition at line 179 of file `uart.c`.

References `vdev_destroy()`.

12.18.2.4 `VDevice*` `uart_create` (`int addr`, `char * name`, `int rel_addr`, `void * data`)

Allocate a new uart structure.

Definition at line 335 of file `uart.c`.

12.18.2.5 void `uart_construct` (`UART_T * uart`, `int addr`, `char * name`, `int rel_addr`)

Constructor for uart object.

Definition at line 356 of file `uart.c`.

References `avr_error`, and `vdev_construct()`.

12.18.2.6 void `uart_destroy` (`void * uart`)

Destructor for uart object.

Definition at line 389 of file `uart.c`.

References `vdev_destroy()`.

12.18.3 Variable Documentation**12.18.3.1 unsigned int `UART_Int_Table`[]**

Initial value:

```
{  
    irq_vect_table_index (UART_RX),  
    irq_vect_table_index (UART_UDRE),  
    irq_vect_table_index (UART_TX)
```

```
}
```

Definition at line 74 of file uart.c.

12.18.3.2 unsigned int UART0_Int_Table[]

Initial value:

```
{
    irq_vect_table_index (USART0_RX),
    irq_vect_table_index (USART0_UDRE),
    irq_vect_table_index (USART0_TX)
}
```

Definition at line 80 of file uart.c.

12.18.3.3 unsigned int UART1_Int_Table[]

Initial value:

```
{
    irq_vect_table_index (USART1_RX),
    irq_vect_table_index (USART1_UDRE),
    irq_vect_table_index (USART1_TX)
}
```

Definition at line 86 of file uart.c.

12.19 usb.c File Reference

Module to simulate the AVR's USB module.

Functions

- void **usb_port_wr** (char *name, uint8_t val)
- uint8_t **usb_port_rd** (char *name)
- VDevice * **usbi_create** (int addr, char *name, int rel_addr, void *data)
- USBInter_T * **usb_intr_new** (int addr, char *name, uint8_t func_mask)
- void **usb_intr_construct** (USBInter_T *usb, int addr, char *name, uint8_t func_mask)
- void **usb_intr_destroy** (void *usb)
- VDevice * **usb_create** (int addr, char *name, int rel_addr, void *data)
- USB_T * **usb_new** (int addr, char *name)
- void **usb_construct** (USB_T *usb, int addr, char *name)
- void **usb_destroy** (void *usb)

12.19.1 Detailed Description

Module to simulate the AVR's USB module.

Definition in file [usb.c](#).

12.19.2 Function Documentation

12.19.2.1 VDevice* usbi_create (int *addr*, char * *name*, int *rel_addr*, void * *data*)

Allocate a new USB interrupt.

Definition at line 78 of file [usb.c](#).

References [avr_error](#).

12.19.2.2 void usb_intr_construct (USBInter_T * *usb*, int *addr*, char * *name*, uint8_t *func_mask*)

Constructor for usb interrupt object.

Definition at line 103 of file [usb.c](#).

References [avr_error](#), and [vdev_construct\(\)](#).

12.19.2.3 void usb_intr_destroy (void * *usb*)

Destructor for usb interrupt object.

Definition at line 181 of file [usb.c](#).

References [vdev_destroy\(\)](#).

12.19.2.4 VDevice* usb_create (int *addr*, char * *name*, int *rel_addr*, void * *data*)

Allocate a new USB structure.

Definition at line 301 of file [usb.c](#).

12.19.2.5 void usb_construct (USB_T * *usb*, int *addr*, char * *name*)

Constructor for new USB object.

Definition at line 321 of file [usb.c](#).

References [avr_error](#), and [vdev_construct\(\)](#).

12.19.2.6 `void usb_destroy (void *usb)`

Destructor for USB object.

Definition at line 480 of file `usb.c`.

References `vdev_destroy()`.

12.20 `utils.c` File Reference

Utility functions.

Functions

- `int str2ffmt (char *str)`
- `uint8_t set_bit_in_byte (uint8_t src, int bit, int val)`
- `uint16_t set_bit_in_word (uint16_t src, int bit, int val)`
- `uint64_t get_program_time (void)`
- `DList * dlist_add (DList *head, AvrClass *data, DListFP_Cmp cmp)`
- `DList * dlist_add_head (DList *head, AvrClass *data)`
- `DList * dlist_delete (DList *head, AvrClass *data, DListFP_Cmp cmp)`
- `void dlist_delete_all (DList *head)`
- `AvrClass * dlist_lookup (DList *head, AvrClass *data, DListFP_Cmp cmp)`
- `AvrClass * dlist_get_head_data (DList *head)`
- `DList * dlist_iterator (DList *head, DListFP_Iter func, void *user_data)`

12.20.1 Detailed Description

Utility functions.

This module provides general purpose utilities.

Definition in file `utils.c`.

12.20.2 Function Documentation

12.20.2.1 `int str2ffmt (char *str)`

Utility function to convert a string to a FileFormatType code.

Definition at line 50 of file `utils.c`.

12.20.2.2 `uint8_t set_bit_in_byte (uint8_t src, int bit, int val)`

Set a bit in `src` to 1 if `val != 0`, clears bit if `val == 0`.

12.20.2.3 `uint16_t set_bit_in_word (uint16_t src, int bit, int val)`

Set a bit in `src` to 1 if `val != 0`, clears bit if `val == 0`.

12.20.2.4 `uint64_t get_program_time (void)`

Return the number of milliseconds of elapsed program time.

Returns:

an unsigned 64 bit number. Time zero is not well defined, so only time differences should be used.

Definition at line 76 of file `utils.c`.

References `avr_error`.

Referenced by `avr_core_run()`.

12.20.2.5 `DList* dlist_add (DList * head, AvrClass * data, DListFP_Cmp cmp)`

Add a new node to the end of the list.

If `cmp` argument is not `NULL`, use `cmp()` to see if node already exists and don't add node if it exists.

It is the responsibility of this function to `unref` data if not added.

Definition at line 159 of file `utils.c`.

References `class_unref()`.

12.20.2.6 `DList* dlist_add_head (DList * head, AvrClass * data)`

Add a new node at the head of the list.

Definition at line 196 of file `utils.c`.

12.20.2.7 `DList* dlist_delete (DList * head, AvrClass * data, DListFP_Cmp cmp)`

Conditionally delete a node from the list.

Delete a node from the list if the node's data matches the specified data. Returns the head of the modified list.

Definition at line 215 of file `utils.c`.

References `avr_error`, and `class_unref()`.

Referenced by `dlist_iterator()`.

12.20.2.8 void dlist_delete_all (DList * head)

Blow away the entire list.

Definition at line 266 of file utils.c.

References class_unref().

Referenced by avr_core_destroy().

12.20.2.9 AvrClass* dlist_lookup (DList * head, AvrClass * data, DListFP_Cmp cmp)

Lookup an item in the list.

Walk the list pointed to by head and return a pointer to the data if found. If not found, return NULL.

Parameters:

head The head of the list to be iterated.

data The data to be passed to the func when it is applied.

cmp A function to be used for comparing the items.

Returns:

A pointer to the data found, or NULL if not found.

Definition at line 291 of file utils.c.

References avr_error.

Referenced by mem_get_vdevice_by_name().

12.20.2.10 AvrClass* dlist_get_head_data (DList * head)

Extract the data from the head of the list.

Returns the data element for the head of the list. If the list is empty, return a NULL pointer.

Parameters:

head The head of the list.

Returns:

A pointer to the data found, or NULL if not found.

Definition at line 321 of file utils.c.

12.20.2.11 DList* dlist_iterator (DList * *head*, DListFP_Iter *func*, void * *user_data*)

Iterate over all elements of the list.

For each element, call the user supplied iterator function and pass it the node data and the *user_data*. If the iterator function return non-zero, remove the node from the list.

Parameters:

head The head of the list to be iterated.

func The function to be applied.

user_data The data to be passed to the *func* when it is applied.

Returns:

A pointer to the head of the possibly modified list.

Definition at line 357 of file *utils.c*.

References *avr_error*, and *dlist_delete()*.

Index

adc.c, [10](#)
 adc_construct, [11](#)
 adc_create, [11](#)
 adc_destroy, [11](#)
 adc_int_create, [10](#)
 adc_intr_construct, [10](#)
 adc_intr_destroy, [10](#)
adc_construct
 adc.c, [11](#)
adc_create
 adc.c, [11](#)
adc_destroy
 adc.c, [11](#)
adc_int_create
 adc.c, [10](#)
adc_intr_construct
 adc.c, [10](#)
adc_intr_destroy
 adc.c, [10](#)
avr_core_add_ext_rd_wr
 avrcore.c, [21](#)
avr_core_async_cb_add
 avrcore.c, [22](#)
avr_core_async_cb_exec
 avrcore.c, [22](#)
avr_core_attach_vdev
 avrcore.c, [16](#)
avr_core_CK_get
 avrcore.c, [18](#)
avr_core_CK_incr
 avrcore.c, [19](#)
avr_core_clk_cb_add
 avrcore.c, [22](#)
avr_core_clk_cb_exec
 avrcore.c, [22](#)
avr_core_destroy
 avrcore.c, [16](#)
avr_core_disable_breakpoints
 avrcore.c, [20](#)
avr_core_dump_core
 avrcore.c, [22](#)
avr_core_enable_breakpoints
 avrcore.c, [20](#)
avr_core_get_sizes
 avrcore.c, [16](#)
avr_core_get_sleep_mode
 avrcore.c, [17](#)
avr_core_get_state
 avrcore.c, [17](#)
avr_core_get_vdev_by_addr
 avrcore.c, [16](#)
avr_core_get_vdev_by_name
 avrcore.c, [16](#)
avr_core_insert_breakpoint
 avrcore.c, [19](#)
avr_core_inst_CKS_get
 avrcore.c, [19](#)
avr_core_inst_CKS_set
 avrcore.c, [19](#)
avr_core_io_display_names
 avrcore.c, [17](#)
avr_core_io_read
 avrcore.c, [18](#)
avr_core_io_write
 avrcore.c, [18](#)
avr_core_irq_clear
 avrcore.c, [19](#)
avr_core_irq_clear_all
 avrcore.c, [19](#)
avr_core_irq_get_pending
 avrcore.c, [19](#)
avr_core_irq_raise
 avrcore.c, [19](#)
avr_core_load_eeeprom
 avrcore.c, [23](#)
avr_core_load_program
 avrcore.c, [22](#)
avr_core_new
 avrcore.c, [16](#)
avr_core_PC_incr
 avrcore.c, [18](#)
avr_core_PC_size
 avrcore.c, [18](#)
avr_core_rampz_get

- avrcore.c, 17
- avr_core_rampz_set
 - avrcore.c, 17
- avr_core_remove_breakpoint
 - avrcore.c, 20
- avr_core_reset
 - avrcore.c, 21
- avr_core_run
 - avrcore.c, 20
- avr_core_set_sleep_mode
 - avrcore.c, 17
- avr_core_set_state
 - avrcore.c, 17
- avr_core_sreg_get_bit
 - avrcore.c, 17
- avr_core_sreg_set_bit
 - avrcore.c, 17
- avr_core_stack_pop
 - avrcore.c, 18
- avr_core_stack_push
 - avrcore.c, 18
- avr_core_step
 - avrcore.c, 20
- avr_error
 - avrerror.c, 24
- avr_free
 - avrmmalloc.c, 27
- avr_malloc
 - avrmmalloc.c, 26
- avr_malloc0
 - avrmmalloc.c, 26
- avr_message
 - avrerror.c, 24
- avr_new
 - avrmmalloc.c, 25
- avr_new0
 - avrmmalloc.c, 25
- avr_realloc
 - avrmmalloc.c, 27
- avr_renew
 - avrmmalloc.c, 26
- avr_strdup
 - avrmmalloc.c, 27
- avr_warning
 - avrerror.c, 24
- avrclass.c, 11
- class_construct, 12
- class_destroy, 12
- class_new, 12
- class_overload_destroy, 12
- class_ref, 13
- class_unref, 13
- avrcore.c, 13
 - avr_core_add_ext_rd_wr, 21
 - avr_core_async_cb_add, 22
 - avr_core_async_cb_exec, 22
 - avr_core_attach_vdev, 16
 - avr_core_CK_get, 18
 - avr_core_CK_incr, 19
 - avr_core_clk_cb_add, 22
 - avr_core_clk_cb_exec, 22
 - avr_core_destroy, 16
 - avr_core_disable_breakpoints, 20
 - avr_core_dump_core, 22
 - avr_core_enable_breakpoints, 20
 - avr_core_get_sizes, 16
 - avr_core_get_sleep_mode, 17
 - avr_core_get_state, 17
 - avr_core_get_vdev_by_addr, 16
 - avr_core_get_vdev_by_name, 16
 - avr_core_insert_breakpoint, 19
 - avr_core_inst_CKS_get, 19
 - avr_core_inst_CKS_set, 19
 - avr_core_io_display_names, 17
 - avr_core_io_read, 18
 - avr_core_io_write, 18
 - avr_core_irq_clear, 19
 - avr_core_irq_clear_all, 19
 - avr_core_irq_get_pending, 19
 - avr_core_irq_raise, 19
 - avr_core_load_eeprom, 23
 - avr_core_load_program, 22
 - avr_core_new, 16
 - avr_core_PC_incr, 18
 - avr_core_PC_size, 18
 - avr_core_rampz_get, 17
 - avr_core_rampz_set, 17
 - avr_core_remove_breakpoint, 20
 - avr_core_reset, 21
 - avr_core_run, 20
 - avr_core_set_sleep_mode, 17
 - avr_core_set_state, 17

- avr_core_sreg_get_bit, 17
- avr_core_sreg_set_bit, 17
- avr_core_stack_pop, 18
- avr_core_stack_push, 18
- avr_core_step, 20
- global_debug_inst_output, 23
- avrerror.c, 23
 - avr_error, 24
 - avr_message, 24
 - avr_warning, 24
- avrmalloc.c, 24
 - avr_free, 27
 - avr_malloc, 26
 - avr_malloc0, 26
 - avr_new, 25
 - avr_new0, 25
 - avr_realloc, 27
 - avr_renew, 26
 - avr_strdup, 27
- BarClass, 3, 4
- BarClass structure definition, 3
- breakpoints, 8
- class_construct
 - avrclass.c, 12
- class_destroy
 - avrclass.c, 12
- class_new
 - avrclass.c, 12
- class_overload_destroy
 - avrclass.c, 12
- class_ref
 - avrclass.c, 13
- class_unref
 - avrclass.c, 13
- decode_init_lookup_table
 - decoder.c, 30
- decode_opcode
 - decoder.c, 30
- decoder.c, 28
 - decode_init_lookup_table, 30
 - decode_opcode, 30
 - decoder_operand_masks, 29
 - mask_A_5, 29
 - mask_A_6, 29
 - mask_k_12, 29
 - mask_k_22, 29
 - mask_K_6, 29
 - mask_k_7, 29
 - mask_K_8, 29
 - mask_q_displ, 29
 - mask_Rd_2, 29
 - mask_Rd_3, 29
 - mask_Rd_4, 29
 - mask_Rd_5, 29
 - mask_reg_bit, 29
 - mask_Rr_3, 29
 - mask_Rr_4, 29
 - mask_Rr_5, 29
 - mask_sreg_bit, 29
- decoder_operand_masks
 - decoder.c, 29
- dev_supp_list_devices
 - devsupp.c, 33
- dev_supp_lookup_device
 - devsupp.c, 33
- device.c, 30
 - vdev_add_addr, 32
 - vdev_construct, 31
 - vdev_def_AddAddr, 31
 - vdev_destroy, 31
 - vdev_get_core, 32
 - vdev_new, 31
 - vdev_read, 32
 - vdev_reset, 32
 - vdev_set_core, 32
 - vdev_write, 32
- devsupp.c, 33
 - dev_supp_list_devices, 33
 - dev_supp_lookup_device, 33
- display.c, 34
 - display_clock, 35
 - display_close, 35
 - display_eeprom, 38
 - display_flash, 37
 - display_io_reg, 36
 - display_io_reg_name, 36
 - display_open, 34
 - display_pc, 36
 - display_reg, 36

- display_send_msg, 35
- display_sram, 37
- display_clock
 - display.c, 35
- display_close
 - display.c, 35
- display_eeprom
 - display.c, 38
- display_flash
 - display.c, 37
- display_io_reg
 - display.c, 36
- display_io_reg_name
 - display.c, 36
- display_open
 - display.c, 34
- display_pc
 - display.c, 36
- display_reg
 - display.c, 36
- display_send_msg
 - display.c, 35
- display_sram
 - display.c, 37
- dlist_add
 - utils.c, 62
- dlist_add_head
 - utils.c, 62
- dlist_delete
 - utils.c, 62
- dlist_delete_all
 - utils.c, 62
- dlist_get_head_data
 - utils.c, 63
- dlist_iterator
 - utils.c, 63
- dlist_lookup
 - utils.c, 63
- example, derived class, 3
- external devices, 7
- flash.c, 38
 - flash_construct, 40
 - flash_destroy, 40
 - flash_dump_core, 40
 - flash_get_size, 40
 - flash_load_from_file, 40
 - flash_new, 40
 - flash_read, 39
 - flash_write, 39
 - flash_write_hi8, 39
 - flash_write_lo8, 39
- flash_construct
 - flash.c, 40
- flash_destroy
 - flash.c, 40
- flash_dump_core
 - flash.c, 40
- flash_get_size
 - flash.c, 40
- flash_load_from_file
 - flash.c, 40
- flash_new
 - flash.c, 40
- flash_read
 - flash.c, 39
- flash_write
 - flash.c, 39
- flash_write_hi8
 - flash.c, 39
- flash_write_lo8
 - flash.c, 39
- FooClass, 3, 5
- FooClass structure definition, 3
- gdb_interact
 - gdbserver.c, 42
- gdbserver.c, 41
 - gdb_interact, 42
- get_program_time
 - utils.c, 62
- global_debug_inst_output
 - avrcore.c, 23
- hwstack_construct
 - stack.c, 53
- hwstack_destroy
 - stack.c, 53
- hwstack_new
 - stack.c, 52
- instruction decoder, 7

- interrupts, [7](#)
- introduction, [1](#)

- mask_A_5
 - [decoder.c, 29](#)
- mask_A_6
 - [decoder.c, 29](#)
- mask_k_12
 - [decoder.c, 29](#)
- mask_k_22
 - [decoder.c, 29](#)
- mask_K_6
 - [decoder.c, 29](#)
- mask_k_7
 - [decoder.c, 29](#)
- mask_K_8
 - [decoder.c, 29](#)
- mask_q_displ
 - [decoder.c, 29](#)
- mask_Rd_2
 - [decoder.c, 29](#)
- mask_Rd_3
 - [decoder.c, 29](#)
- mask_Rd_4
 - [decoder.c, 29](#)
- mask_Rd_5
 - [decoder.c, 29](#)
- mask_reg_bit
 - [decoder.c, 29](#)
- mask_Rr_3
 - [decoder.c, 29](#)
- mask_Rr_4
 - [decoder.c, 29](#)
- mask_Rr_5
 - [decoder.c, 29](#)
- mask_sreg_bit
 - [decoder.c, 29](#)
- mem_attach
 - [memory.c, 43](#)
- mem_construct
 - [memory.c, 43](#)
- mem_destroy
 - [memory.c, 43](#)
- mem_dump_core
 - [memory.c, 45](#)
- mem_get_vdevice_by_addr
 - [memory.c, 44](#)
- mem_get_vdevice_by_name
 - [memory.c, 44](#)
- mem_io_fetch
 - [memory.c, 45](#)
- mem_new
 - [memory.c, 43](#)
- mem_read
 - [memory.c, 44](#)
- mem_reset
 - [memory.c, 45](#)
- mem_write
 - [memory.c, 44](#)
- memory functions, [1](#)
- memory macros, [2](#)
- memory management, [1](#)
- memory.c, [42](#)
 - [mem_attach, 43](#)
 - [mem_construct, 43](#)
 - [mem_destroy, 43](#)
 - [mem_dump_core, 45](#)
 - [mem_get_vdevice_by_addr, 44](#)
 - [mem_get_vdevice_by_name, 44](#)
 - [mem_io_fetch, 45](#)
 - [mem_new, 43](#)
 - [mem_read, 44](#)
 - [mem_reset, 45](#)
 - [mem_write, 44](#)
- memstack_construct
 - [stack.c, 53](#)
- memstack_destroy
 - [stack.c, 54](#)
- memstack_new
 - [stack.c, 53](#)

- object referencing, [6](#)
- objects, [2](#)
- ocreg16_construct
 - [timers.c, 56](#)
- ocreg16_create
 - [timers.c, 56](#)

- port_add_ext_rd_wr
 - [ports.c, 47](#)
- port_create
 - [ports.c, 46](#)

- port_ext_disable
 - ports.c, 46
- port_ext_enable
 - ports.c, 47
- ports.c, 46
 - port_add_ext_rd_wr, 47
 - port_create, 46
 - port_ext_disable, 46
 - port_ext_enable, 47
- set_bit_in_byte
 - utils.c, 61
- set_bit_in_word
 - utils.c, 61
- sig.c, 47
 - signal_has_occurred, 48
 - signal_reset, 48
 - signal_watch_start, 48
 - signal_watch_stop, 48
- signal_has_occurred
 - sig.c, 48
- signal_reset
 - sig.c, 48
- signal_watch_start
 - sig.c, 48
- signal_watch_stop
 - sig.c, 48
- sp_create
 - stack.c, 53
- spi.c, 49
 - spi_construct, 50
 - spi_create, 50
 - spi_destroy, 50
 - spi_intr_construct, 49
 - spi_intr_destroy, 50
 - spii_create, 49
- spi_construct
 - spi.c, 50
- spi_create
 - spi.c, 50
- spi_destroy
 - spi.c, 50
- spi_intr_construct
 - spi.c, 49
- spi_intr_destroy
 - spi.c, 50
- spii_create
 - spi.c, 49
- stack.c, 50
 - hwstack_construct, 53
 - hwstack_destroy, 53
 - hwstack_new, 52
 - memstack_construct, 53
 - memstack_destroy, 54
 - memstack_new, 53
 - sp_create, 53
 - stack_construct, 51
 - stack_destroy, 51
 - stack_new, 51
 - stack_pop, 52
 - stack_push, 52
- stack_construct
 - stack.c, 51
- stack_destroy
 - stack.c, 51
- stack_new
 - stack.c, 51
- stack_pop
 - stack.c, 52
- stack_push
 - stack.c, 52
- str2ffmt
 - utils.c, 61
- timer0_construct
 - timers.c, 55
- timer0_create
 - timers.c, 55
- timer0_destroy
 - timers.c, 55
- timer16_construct
 - timers.c, 56
- timer16_create
 - timers.c, 56
- timer_int_create
 - timers.c, 55
- timer_intr_construct
 - timers.c, 55
- timer_intr_destroy
 - timers.c, 55
- timers.c, 54
 - ocreg16_construct, 56

- ocreg16_create, 56
- timer0_construct, 55
- timer0_create, 55
- timer0_destroy, 55
- timer16_construct, 56
- timer16_create, 56
- timer_int_create, 55
- timer_intr_construct, 55
- timer_intr_destroy, 55
- uart.c, 57
 - UART0_Int_Table, 59
 - UART1_Int_Table, 59
 - uart_construct, 58
 - uart_create, 58
 - uart_destroy, 58
 - uart_int_create, 57
 - UART_Int_Table, 58
 - uart_intr_construct, 57
 - uart_intr_destroy, 58
- UART0_Int_Table
 - uart.c, 59
- UART1_Int_Table
 - uart.c, 59
- uart_construct
 - uart.c, 58
- uart_create
 - uart.c, 58
- uart_destroy
 - uart.c, 58
- uart_int_create
 - uart.c, 57
- UART_Int_Table
 - uart.c, 58
- uart_intr_construct
 - uart.c, 57
- uart_intr_destroy
 - uart.c, 58
- usb.c, 59
 - usb_construct, 60
 - usb_create, 60
 - usb_destroy, 60
 - usb_intr_construct, 60
 - usb_intr_destroy, 60
 - usbi_create, 60
- usb_construct
 - usb.c, 60
- usb_create
 - usb.c, 60
- usb_destroy
 - usb.c, 60
- usb_intr_construct
 - usb.c, 60
- usb_intr_destroy
 - usb.c, 60
- usbi_create
 - usb.c, 60
- utils.c, 61
 - dlist_add, 62
 - dlist_add_head, 62
 - dlist_delete, 62
 - dlist_delete_all, 62
 - dlist_get_head_data, 63
 - dlist_iterator, 63
 - dlist_lookup, 63
 - get_program_time, 62
 - set_bit_in_byte, 61
 - set_bit_in_word, 61
 - str2ffmt, 61
- vdev_add_addr
 - device.c, 32
- vdev_construct
 - device.c, 31
- vdev_def_AddAddr
 - device.c, 31
- vdev_destroy
 - device.c, 31
- vdev_get_core
 - device.c, 32
- vdev_new
 - device.c, 31
- vdev_read
 - device.c, 32
- vdev_reset
 - device.c, 32
- vdev_set_core
 - device.c, 32
- vdev_write
 - device.c, 32
- virtual devices, 7

watchpoints, [8](#)