

NAME

foo2zjs-wrapper – Convert Postscript into a ZJS printer stream

SYNOPSIS

foo2zjs-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2zjs-wrapper is a Foomatic compatible printer wrapper for the **foo2zjs** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Print in color (else monochrome).

-C *colormode*

Color correction mode [0].

- 0 Best compromise
- 1 Photos (using m2300w CRDs)
- 2 Photos and text (using m2300w CRDs)
- 3 Graphics and text (using m2300w CRDs)
- 10 ICM color profile (using -G *.icm file)

-d *duplex*

Duplex code to send to printer [1].

| 1 off | 2 long edge | 3 short edge

-m *media*

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

-p *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

- n** *copies*
Number of copies [1].
- r** *xresxyres*
Set device resolution in pixels/inch [1200x600].
- s** *source*
Source (Input Slot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto
- t** Draft mode. Every other pixel is white.
- 2** Print in 2-up. Requires the **psutils** package.
- 4** Print in 4-up. Requires the **psutils** package.
- o** *orient*
Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

- u** *xoff xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l** *xoff xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L** *mask*
Send the logical clipping values from -u/-l in the ZjStream. **foo2zjs-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts
- P** Do not send START_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.
- X** *padlen*
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.
- z** *model*
Model: 0=2300DL, 1=HP1020. Default is 0.

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as `-g“-dDITHERPPI=nnn”`, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

-G *gamma-fi le.ps*

Prepend *gamma-fi le.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
`{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer`

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2zjs** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2zjs-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2zjs-wrapper -c testpage.ps > testpage.zc
```

FILES

`/usr/bin/foo2zjs-wrapper`

SEE ALSO

foo2zjs(1), **zjsdecode(1)**

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2zjs.rkkda.com/>

NAME

foo2zjs – Convert Ghostscript pbmraw or bitcmyk format into a ZJS printer stream

SYNOPSIS

foo2zjs [*options*] <*pbmraw-fi le*> <*zjs-fi le*>

foo2zjs [*options*] <*bitcmyk-fi le*> <*zjs-fi le*>

foo2zjs [*options*] <*pksmraw-fi le*> <*zjs-fi le*>

DESCRIPTION

foo2zjs converts Ghostscript pbmraw, bitcmyk, or pksmraw output formats to monochrome or color ZJS streams, for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Force color mode if autodetect doesn't work.

-d duplex

Duplex code to send to printer [1].

| 1 off | 2 long edge | 3 short edge

-g xpixxpix

Set page dimensions in pixels [10200x6600].

-m media

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

-p paper

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n copies

Number of copies [1].

-r xresxyres

Set device resolution in pixels/inch [1200x600].

-s *source*
Source (InputSlot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

-t Draft mode. Every other pixel is white.

-J *filename*
Filename string to send to printer.

-U *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

-u *xoff* *xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

-l *xoff* *xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

-L *mask*
Send logical clipping amounts implied by -u/-l in the ZjStream [3].

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts

-P Do not send START_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.

-A AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmymk input only.

-B BlackClears: K=1 forces C,M,Y to 0. Works with bitcmymk input only.

-X *padlen*
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

-z *model*
Model: 0=2300DL, 1=HP1020. Default is 0.

Debugging Options

These options are used for debugging **foo2zjs**.

-S *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

1	Cyan
2	Magenta
3	Yellow
4	Black

-D *level*
Set Debug level [0].

EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r1200x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g10200x6600 -r1200x600 -sDEVICE=bitcmk
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zc
```

FILES

`/usr/bin/foo2zjs`

SEE ALSO

`foo2zjs-wrapper(1)`, `zjsdecode(1)`

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2zjs.rkkda.com/>

NAME

zjsdecode – Decode a ZjStream into human readable form.

SYNOPSIS

zjsdecode [*options*] <*zjs-fi le*

DESCRIPTION

zjsdecode decodes a ZjStream into human readable form.

A ZjStream is the printer language used by some Minolta/QMS and HP printers, such as the 2300DL and LJ-1000.

More information on Zenographics ZjStream can be found at:

<http://ddk.zeno.com>

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

-d *basename*

 Baseline of .pbm fi le for saving decompressed planes.

-r *basename*

 Baseline of .jbg fi le for saving raw planes

-h Print hex fi le offsets.

-o Print fi le offsets.

-D *level*

 Set Debug level [0].

EXAMPLES

Decode an ZjStream fi le created by foo2zjs.

```
$ zjsdecode < testpage.zm
ZJT_START_DOC, 3 items
    ZJI_PAGECOUNT, 0 (0x0)
    ZJI_DMDUPLEX, 1 (0x1)
    ZJI_QUANTITY, 1 (0x1)
ZJT_START_PAGE, 17 items
    ZJI_0x17, 0 (0x0)
    ZJI_0x16, 1 (0x1)
    ZJI_VIDEO_X, 10200 (0x27d8)
    ZJI_VIDEO_Y, 6600 (0x19c8)
    ZJI_VIDEO_BPP, 1 (0x1)
    ZJI_RASTER_X, 10200 (0x27d8)
    ZJI_RASTER_Y, 6600 (0x19c8)
    ZJI_OFFSET_X, 0 (0x0)
    ZJI_OFFSET_Y, 0 (0x0)
    ZJI_NBIE, 1 (0x1)
    ZJI_RESOLUTION_X, 1200 (0x4b0)
    ZJI_RESOLUTION_Y, 600 (0x258)
    ZJI_DMDEFAULTSOURCE, 7 (0x7)
    ZJI_DMCOPIES, 1 (0x1)
    ZJI_DMPAPER, 1 (0x1)
    ZJI_DMMEDIATYPE, 1 (0x1)
    ZJI_MINOLTA_PAGE_NUMBER, 1 (0x1)
```

```
ZJT_JBIG_BIH, 0 items
  Data: 20 bytes
      DL = 0, D = 0, P = 1, - = 0, XY = 10200 x 6600
      L0 = 128, MX = 16, MY = 0
      Order   = 3  ILEAVE SMID
      Options = 92  LRLTWO TPDON TPBON DPON
      52 stripes, 0 layers, 1 planes
ZJT_JBIG_BID, 0 items
  Data: 65536 bytes
ZJT_JBIG_BID, 0 items
  Data: 29120 bytes
ZJT_END_JBIG, 0 items
ZJT_END_PAGE, 0 items
ZJT_END_DOC, 0 items
```

FILES

`/usr/bin/zjsdecode`

SEE ALSO

`foo2zjs-wrapper(1)`, `foo2zjs(1)`, `jbg2pbm(1)`

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2zjs.rkkda.com/>

NAME

foo2oak-wrapper – Convert Postscript into an OAKT printer stream

SYNOPSIS

foo2oak-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2oak-wrapper is a Foomatic compatible printer wrapper for the **foo2oak** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Oak Technology OAKT printer format for driving the HP Color LaserJet 1500 laser printer and other OAKT-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Number of bits per plane (1 or 2) [1].

-c Print in color (else monochrome).

-m *media*

Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

-p *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [600x600].

-s *source*

Source (Input Slot) code to send to printer [7].

1	upper	4	manual
7	auto		

-2 Print in 2-up. Requires the **psutils** package.

-4 Print in 4-up. Requires the **psutils** package.

-o *orient*

Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2oak** for a particular printer.

-u *xoff* *xyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-l *xoff* *xyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-L *mask*

Send the logical clipping values from -u/-l in the OAKT stream. **foo2oak-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

-G *gamma-fi* *le.ps*

Prepend *gamma-fi* *le.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the *fi* *le* might contain:
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

-I *intent*

Select *profile* intent from the ICM *file*. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2oak** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome OAKT stream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2oak-wrapper testpage.ps > testpage.oak
oakdecode < testpage.oak
lpr -P raw testpage.oak
```

Create a color OAKT stream from a Postscript document:

```
foo2oak-wrapper -c testpage.ps > testpage.oak
```

FILES

/usr/bin/foo2oak-wrapper

SEE ALSO

foo2oak(1), oak(1)

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2oak.rkkda.com/>

NAME

foo2oak – Convert Ghostscript pbmraw, pgmraw or bitcmyk format into an OAKT printer stream

SYNOPSIS

foo2oak [*options*] <*pbmraw-fi le*>*OAKT-fi le*

foo2oak [*options*] <*pgmraw-fi le*>*OAKT-fi le*

foo2oak [*options*] <*bitcmyk-fi le*>*OAKT-fi le*

DESCRIPTION

foo2oak converts Ghostscript pbmraw or bitcmyk output formats to monochrome or color OAKT streams, for driving the HP color Laserjet 1500 laser printer and other OAKT-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Force color mode if autodetect doesn't work.

-g *xpixxypix*
Set page dimensions in pixels [10200x6600].

-m *media*
Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

-p *paper*
Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

-n *copies*
Number of copies [1].

-r *xresxyres*
Set device resolution in pixels/inch [600x600].

-s *source*
Source (InputSlot) code to send to printer [7].

1	tray1	4	manual
7	auto		

-J *fi lename*
Filename string to send to printer.

-U *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2oak** for a particular printer.

- u** *xoff xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].
- l** *xoff xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].
- L** *mask*
Send logical clipping amounts implied by -u/-l in the OAKT stream [3].
 - 0 don't send any logical clipping amounts
 - 1 only send Y clipping amount
 - 2 only send X clipping amount
 - 3 send both X and Y clipping amounts
- A** Turn off: conversion of C=1,M=1,Y=1 to pure black.
- B** Turn off: K=1 forces C,M,Y to 0.

Debugging Options

These options are used for debugging **foo2oak**.

- S** *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.
 - 1 Cyan
 - 2 Magenta
 - 3 Yellow
 - 4 Black
- D** *level*
Set Debug level [0].

EXAMPLES

Create a black and white OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

Create a color OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmk
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

FILES

/usr/bin/foo2oak

SEE ALSO

foo2oak-wrapper(1), **oakdecode(1)**

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2oak.rkkda.com/>

NAME

oakdecode – Decode an OAKT printer stream into human readable form.

SYNOPSIS

oakdecode [*options*] <*OAKT-file*

DESCRIPTION

oakdecode decodes an OAKT printer stream into human readable form.

An OAKT printer stream is the printer language used by the HP Color LaserJet 1500 and other printers.

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

- d** *basename*
 Basename of .pbm file for saving decompressed planes.
- r** *basename*
 Basename of .jbg file for saving raw planes
- i** Suppress display of image records.
- o** Print file offsets.
- D** *level*
 Set Debug level [0].

EXAMPLES

Decode an OAKT file created by foo2oak.

```
$ oakdecode < testpage.oak
0d (80) 1 OTHER
0c (64) Wed Nov 05 16:30:50 2003      a07d3   100005   32001e
0a (80) testpage.pdf
14 (16) (no args)
28 (16) Source=Tray1
29 (80) PaperType=0 UNK8=2,0,0,0, blanks(63)
2a (32) Copies=1      UNK=0
2b (32) papercode=25  xwid=4648      ywid=9000      UNK=0
33 (64)
      u0      u1      w      h      resx      resy      nBits
      x0      x0      2128    4300    600      600      x1
15 (16) (no args)
      bih0      w      h      l0      bih5      dlen      plen      unk      yOff      P      subP
3c (64) 00010000 2176 256 256 58030020 1050 1056 000 64 3 0
      DL = 0, D = 0, P = 1, - = 0, XY = 2176 x 256
      L0 = 256, MX = 32, MY = 0
      Order   = 3  ILEAVE SMID
      Options = 88  LRLTWO TPDON TPBON
      1 stripes, 0 layers, 1 planes
3c (64) 00010000 2176 256 256 58030020 3668 3680 000 320 3 0
3c (64) 00010000 2176 256 256 58030020 1463 1472 000 640 3 0
3c (64) 00010000 2176 256 256 58030020 1975 1984 000 896 3 0
3c (64) 00010000 2176 224 224 58030020 2744 2752 000 1152 3 0
3c (64) 00010000 2176 256 256 58030020 988 992 000 1440 3 0
3c (64) 00010000 2176 256 256 58030020 2892 2896 000 1696 3 0
3c (64) 00010000 2176 256 256 58030020 3634 3648 000 1952 3 0
```

oakdecode(1)

oakdecode(1)

```
3c (64) 00010000 2176 256 256 58030020 3236 3248 000 2208 3 0
3c (64) 00010000 2176 256 256 58030020 2279 2288 000 2464 3 0
3c (64) 00010000 2176 256 256 58030020 3746 3760 000 2720 3 0
3c (64) 00010000 2176 200 200 58030020 2404 2416 000 2976 3 0
3c (64) 00010000 2176 256 256 58030020 3114 3120 000 3240 3 0
3c (64) 00010000 2176 96 96 58030020 1142 1152 000 3496 3 0
3c (64) 00010000 2176 256 256 58030020 2094 2112 000 3752 3 0
3c (64) 00010000 2176 256 256 58030020 1319 1328 000 4008 3 0
3c (64) 00010000 2176 36 36 58030020 208 224 000 4264 3 0
17 (16) (no args)
18 (16) UNK=0
0b (16) (no args)
```

FILES

`/usr/bin/oakdecode`

SEE ALSO

`foo2oak-wrapper(1)`, `foo2oak(1)`, `jbg2pbm(1)`

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2oak.rkkda.com/>

NAME

foo2hp2600-wrapper – Convert Postscript into a ZJS printer stream

SYNOPSIS

foo2hp2600-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2hp2600-wrapper is a Foomatic compatible printer wrapper for the **foo2hp** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Number of bits per plane. 1 or 2. [1].

-c Print in color (else monochrome).

-d *duplex*

Duplex code to send to printer [1].

| 1 off | 4 manual long edge | 5 manual short edge

-m *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

-p *paper*

Paper size code to send to printer [1].

1 letter	9 A4
5 legal	11 A5

7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

- n** *copies*
Number of copies [1].
- r** *xresxyres*
Set device resolution in pixels/inch [1200x600].
- s** *source*
Source (Input Slot) code to send to printer [7].

1	tray 2	4	manual/tray 1
2	tray 3	7	auto
- t** Draft mode. Every other pixel is white.
- 2** Print in 2-up. Requires the **psutils** package.
- 4** Print in 4-up. Requires the **psutils** package.
- o** *orient*
Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2hp** for a particular printer.

- u** *xoffxyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l** *xoffxyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L** *mask*
Send the logical clipping values from -u/-l in the ZjStream. **foo2hp2600-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts
- P** Do not send START_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.
- X** *padlen*
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as `-g“-dDITHERPPI=nnn”`, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. If *profile.icm* is *none.icm*, then prepare for ordering a ICM custom printer profile (i.e. from www.ICCFactory.com).

-G *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
`{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer`

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2hp** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2hp2600-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2hp2600-wrapper -c testpage.ps > testpage.zc
```

FILES

`/usr/bin/foo2hp2600-wrapper`

SEE ALSO

foo2hp(1), **zjsdecode(1)**

AUTHOR

Rick Richardson <rickr@mn.rr.com>
<http://foo2hp.rkkda.com/>

NAME

foo2hp – Convert Ghostscript pbmraw or bitcmk format into a ZJS printer stream

SYNOPSIS

foo2hp [*options*] <*pbmraw-fi le*>*zjs-fi le*

foo2hp [*options*] <*bitcmk-fi le*>*zjs-fi le*

foo2hp [*options*] <*cups-fi le*>*zjs-fi le*

DESCRIPTION

foo2hp converts Ghostscript pbmraw, bitcmk, or cups output formats to monochrome or color ZJS streams, for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Bits per plane if autodetect doesn't work (1 or 2) [1].

-c Force color mode if autodetect doesn't work.

-d *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
		4	manual " "	5	manual " "

-g *xpixxypix*

Set page dimensions in pixels [10200x6600].

-m *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

-p *paper*

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [600x600].

-s *source*

Source (InputSlot) code to send to printer [7].

1	tray 2	7	auto
2	tray 1		

-t Draft mode. Every other pixel is white.

-J *fi lename*

Filename string to send to printer.

-U *username*

Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2hp** for a particular printer.

-u *xoffxyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

-l *xoffxyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

-L *mask*

Send logical clipping amounts implied by -u/-l in the ZjStream [3].

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

-P Do not send START_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.

-A AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmk input only.

-B BlackClears: K=1 forces C,M,Y to 0. Works with bitcmk input only.

-X *padlen*

Add extra zero padding to the end of BID segments. The default is 16 bytes.

Debugging Options

These options are used for debugging **foo2hp**.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan

- 2 Magenta
- 3 Yellow
- 4 Black

-D level

Set Debug level [0].

EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmyk
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zc
```

FILES

`/usr/bin/foo2hp`

SEE ALSO

`foo2hp2600-wrapper(1)`, `zjsdecode(1)`

AUTHOR

Rick Richardson <rickr@mn.rr.com>

<http://foo2hp.rkkda.com/>

