

NAME

foo2zjs-wrapper – Convert Postscript into a ZJS printer stream

SYNOPSIS

foo2zjs-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2zjs-wrapper is a Foomatic compatible printer wrapper for the **foo2zjs** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Print in color (else monochrome).

-C *colormode*

Color correction mode [0].

- 0 Best compromise
- 1 Photos (using m2300w CRDs)
- 2 Photos and text (using m2300w CRDs)
- 3 Graphics and text (using m2300w CRDs)
- 10 ICM color profile (using -G *.icm file)

-d *duplex*

Duplex code to send to printer [1].

| 1 off | 2 long edge | 3 short edge

-m *media*

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

-p *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

- n** *copies*
Number of copies [1].
- r** *xresxyres*
Set device resolution in pixels/inch [1200x600].
- s** *source*
Source (Input Slot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto
- t** Draft mode. Every other pixel is white.
- 2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18**
Print in N-up. Requires the **psutils** package.
- o** *orient*
Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

- u** *xoffxyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l** *xoffxyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L** *mask*
Send the logical clipping values from -u/-l in the ZjStream. **foo2zjs-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts
- P** Do not send START_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.
- X** *padlen*
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.
- z** *model*
Model: 0=2300DL, 1=HP1020. Default is 0.

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

-G *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2zjs** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2zjs-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2zjs-wrapper -c testpage.ps > testpage.zc
```

FILES

/usr/bin/foo2zjs-wrapper

SEE ALSO

foo2zjs(1), **zjsdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2zjs.rkkda.com/>

NAME

foo2zjs – Convert Ghostscript pbmraw or bitcmk format into a ZJS printer stream

SYNOPSIS

foo2zjs [*options*] <*pbmraw-file*> *zjs-file*

foo2zjs [*options*] <*bitcmk-file*> *zjs-file*

foo2zjs [*options*] <*pksmraw-file*> *zjs-file*

DESCRIPTION

foo2zjs converts Ghostscript pbmraw, bitcmk, or pksmraw output formats to monochrome or color ZJS streams, for driving the Minolta/QMS 2300 DL network color laser printer and other Zenographics-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Force color mode if autodetect doesn't work.

-d *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-g *xpixxypix*

Set page dimensions in pixels [10200x6600].

-m *media*

Media code to send to printer [1].

Media	2300DL	2200DL
standard	1	1
transparency	2	2
envelope	257	na
letterhead	259	na
thick	261	4
postcard	262	na
labels	263	3

-p *paper*

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [1200x600].

-s *source*
Source (InputSlot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

-t Draft mode. Every other pixel is white.

-J *filename*
Filename string to send to printer.

-U *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2zjs** for a particular printer.

-u *xoff* *xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

-l *xoff* *xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

-L *mask*
Send logical clipping amounts implied by -u/-l in the ZjStream [3].

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

-P Do not send START_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.

-A AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmk input only.

-B BlackClears: K=1 forces C,M,Y to 0. Works with bitcmk input only.

-X *padlen*
Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

-z *model*
Model: 0=2300DL, 1=HP1020. Default is 0.

Debugging Options

These options are used for debugging **foo2zjs**.

-S *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*
Set Debug level [0].

EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r1200x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g10200x6600 -r1200x600 -sDEVICE=bitcmrk
-sOutputFile=- - < testpage.ps
| foo2zjs -r1200x600 -g10200x6600 -p1 >testpage.zc
```

FILES

`/usr/bin/foo2zjs`

SEE ALSO

`foo2zjs-wrapper(1)`, `zjsdecode(1)`

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2zjs.rkkda.com/>

NAME

zjsdecode – Decode a ZjStream into human readable form.

SYNOPSIS

zjsdecode [*options*] <*zjs-file*

DESCRIPTION

zjsdecode decodes a ZjStream into human readable form.

A ZjStream is the printer language used by some Minolta/QMS and HP printers, such as the 2300DL and LJ-1000.

More information on Zenographics ZjStream can be found at:

<http://ddk.zeno.com>

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

-d *basename*

Basename of .pbm file for saving decompressed planes.

-r *basename*

Basename of .jbg file for saving raw planes

-h Print hex file offsets.

-o Print file offsets.

-D *level*

Set Debug level [0].

EXAMPLES

Decode an ZjStream file created by foo2zjs.

```
$ zjsdecode < testpage.zm
ZJT_START_DOC, 3 items
    ZJI_PAGECOUNT, 0 (0x0)
    ZJI_DMDUPLEX, 1 (0x1)
    ZJI_QUANTITY, 1 (0x1)
ZJT_START_PAGE, 17 items
    ZJI_0x17, 0 (0x0)
    ZJI_0x16, 1 (0x1)
    ZJI_VIDEO_X, 10200 (0x27d8)
    ZJI_VIDEO_Y, 6600 (0x19c8)
    ZJI_VIDEO_BPP, 1 (0x1)
    ZJI_RASTER_X, 10200 (0x27d8)
    ZJI_RASTER_Y, 6600 (0x19c8)
    ZJI_OFFSET_X, 0 (0x0)
    ZJI_OFFSET_Y, 0 (0x0)
    ZJI_NBIE, 1 (0x1)
    ZJI_RESOLUTION_X, 1200 (0x4b0)
    ZJI_RESOLUTION_Y, 600 (0x258)
    ZJI_DMDEFAULTSOURCE, 7 (0x7)
    ZJI_DMCOPIES, 1 (0x1)
    ZJI_DMPAPER, 1 (0x1)
    ZJI_DMEDIATYPE, 1 (0x1)
    ZJI_MINOLTA_PAGE_NUMBER, 1 (0x1)
```

```
ZJT_JBIG_BIH, 0 items
  Data: 20 bytes
    DL = 0, D = 0, P = 1, - = 0, XY = 10200 x 6600
    L0 = 128, MX = 16, MY = 0
    Order    = 3   ILEAVE SMID
    Options = 92   LRLTWO TPDON TPBON DPON
    52 stripes, 0 layers, 1 planes
ZJT_JBIG_BID, 0 items
  Data: 65536 bytes
ZJT_JBIG_BID, 0 items
  Data: 29120 bytes
ZJT_END_JBIG, 0 items
ZJT_END_PAGE, 0 items
ZJT_END_DOC, 0 items
```

FILES

/usr/bin/zjsdecode

SEE ALSO

foo2zjs-wrapper(1), **foo2zjs(1)**, **jbg2pbm(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2zjs.rkkda.com/>

NAME

foo2oak-wrapper – Convert Postscript into an OAKT printer stream

SYNOPSIS

foo2oak-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2oak-wrapper is a Foomatic compatible printer wrapper for the **foo2oak** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Oak Technology OAKT printer format for driving the HP Color LaserJet 1500 laser printer and other OAKT-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Number of bits per plane (1 or 2) [1].

-c Print in color (else monochrome).

-m *media*

Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

-p *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [600x600].

-s *source*

Source (Input Slot) code to send to printer [7].

1	upper	4	manual
7	auto		

-2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18

Print in N-up. Requires the **psutils** package.

-o *orient*

Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2oak** for a particular printer.

-u *xoff* *xyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-l *xoff* *xyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-L *mask*

Send the logical clipping values from -u/-l in the OAKT stream. **foo2oak-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

-G *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2oak** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome OAKT stream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2oak-wrapper testpage.ps > testpage.oak
oakdecode < testpage.oak
lpr -P raw testpage.oak
```

Create a color OAKT stream from a Postscript document:

```
foo2oak-wrapper -c testpage.ps > testpage.oak
```

FILES

/usr/bin/foo2oak-wrapper

SEE ALSO

foo2oak(1), **oak(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2oak.rkkda.com/>

NAME

foo2oak – Convert Ghostscript pbmraw, pgmraw or bitcmk format into an OAKT printer stream

SYNOPSIS

foo2oak [*options*] <*pbmraw-file*> *OAKT-file*

foo2oak [*options*] <*pgmraw-file*> *OAKT-file*

foo2oak [*options*] <*bitcmk-file*> *OAKT-file*

DESCRIPTION

foo2oak converts Ghostscript pbmraw or bitcmk output formats to monochrome or color OAKT streams, for driving the HP color Laserjet 1500 laser printer and other OAKT-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Force color mode if autodetect doesn't work.

-g *xpixxypix*
Set page dimensions in pixels [10200x6600].

-m *media*
Media code to send to printer [1].

1	standard	259	letterhead
2	transparency	261	thickstock
3	glossy	262	postcard
257	envelope	263	labels

-p *paper*
Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5

-n *copies*
Number of copies [1].

-r *xresxyres*
Set device resolution in pixels/inch [600x600].

-s *source*
Source (InputSlot) code to send to printer [7].

1	tray1	4	manual
7	auto		

-J *filename*
Filename string to send to printer.

-U *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2oak** for a particular printer.

- u** *xoff* *xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].
- l** *xoff* *xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].
- L** *mask*
Send logical clipping amounts implied by -u/-l in the OAKT stream [3].
 - 0 don't send any logical clipping amounts
 - 1 only send Y clipping amount
 - 2 only send X clipping amount
 - 3 send both X and Y clipping amounts
- A** Turn off: conversion of C=1,M=1,Y=1 to pure black.
- B** Turn off: K=1 forces C,M,Y to 0.

Debugging Options

These options are used for debugging **foo2oak**.

- S** *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.
 - 1 Cyan
 - 2 Magenta
 - 3 Yellow
 - 4 Black
- D** *level*
Set Debug level [0].

EXAMPLES

Create a black and white OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

Create a color OAKT stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmk
-sOutputFile=- - < testpage.ps
| foo2oak -r600x600 -g5100x6600 -p1 >testpage.oak
```

FILES

/usr/bin/foo2oak

SEE ALSO

foo2oak-wrapper(1), **oakdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2oak.rkkda.com/>

NAME

oakdecode – Decode an OAKT printer stream into human readable form.

SYNOPSIS

oakdecode [*options*] <*OAKT-file*

DESCRIPTION

oakdecode decodes an OAKT printer stream into human readable form.

An OAKT printer stream is the printer language used by the HP Color LaserJet 1500 and other printers.

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

-d *basename*

 Basename of .pbm file for saving decompressed planes.

-r *basename*

 Basename of .jbg file for saving raw planes

-i Suppress display of image records.

-o Print file offsets.

-D *level*

 Set Debug level [0].

EXAMPLES

Decode an OAKT file created by foo2oak.

```
$ oakdecode < testpage.oak
0d (80) 1 OTHER
0c (64) Wed Nov 05 16:30:50 2003          a07d3    100005    32001e
0a (80) testpage.pdf
14 (16) (no args)
28 (16) Source=Tray1
29 (80) PaperType=0 UNK8=2,0,0,0, blanks(63)
2a (32) Copies=1          UNK=0
2b (32) papercode=25      xwid=4648          ywid=9000          UNK=0
33 (64)
        u0      u1      w      h      resx      resy      nBits
        x0      x0      2128    4300    600      600      x1
15 (16) (no args)
        bih0      w      h      l0      bih5      dlen      plen      unk      yOff      P      subP
3c (64) 00010000 2176 256 256 58030020 1050 1056 000 64 3 0
        DL = 0, D = 0, P = 1, - = 0, XY = 2176 x 256
        L0 = 256, MX = 32, MY = 0
        Order   = 3 ILEAVE SMID
        Options = 88 LRLTWO TPDON TPBON
        1 stripes, 0 layers, 1 planes
3c (64) 00010000 2176 256 256 58030020 3668 3680 000 320 3 0
3c (64) 00010000 2176 256 256 58030020 1463 1472 000 640 3 0
3c (64) 00010000 2176 256 256 58030020 1975 1984 000 896 3 0
3c (64) 00010000 2176 224 224 58030020 2744 2752 000 1152 3 0
3c (64) 00010000 2176 256 256 58030020 988 992 000 1440 3 0
3c (64) 00010000 2176 256 256 58030020 2892 2896 000 1696 3 0
3c (64) 00010000 2176 256 256 58030020 3634 3648 000 1952 3 0
```

oakdecode(1)

oakdecode(1)

```
3c (64) 00010000 2176 256 256 58030020 3236 3248 000 2208 3 0
3c (64) 00010000 2176 256 256 58030020 2279 2288 000 2464 3 0
3c (64) 00010000 2176 256 256 58030020 3746 3760 000 2720 3 0
3c (64) 00010000 2176 200 200 58030020 2404 2416 000 2976 3 0
3c (64) 00010000 2176 256 256 58030020 3114 3120 000 3240 3 0
3c (64) 00010000 2176 96 96 58030020 1142 1152 000 3496 3 0
3c (64) 00010000 2176 256 256 58030020 2094 2112 000 3752 3 0
3c (64) 00010000 2176 256 256 58030020 1319 1328 000 4008 3 0
3c (64) 00010000 2176 36 36 58030020 208 224 000 4264 3 0
17 (16) (no args)
18 (16) UNK=0
0b (16) (no args)
```

FILES

/usr/bin/oakdecode

SEE ALSO

foo2oak-wrapper(1), **foo2oak(1)**, **jbg2pbm(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2oak.rkkda.com/>

NAME

foo2hp2600-wrapper – Convert Postscript into a ZJS printer stream

SYNOPSIS

foo2hp2600-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2hp2600-wrapper is a Foomatic compatible printer wrapper for the **foo2hp** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics ZjStream printer format for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Number of bits per plane. 1 or 2. [1].

-c Print in color (else monochrome).

-d *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-m *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

-p *paper*

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5

7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [1200x600].

-s *source*

Source (Input Slot) code to send to printer [7].

1	tray 2	4	manual/tray 1
2	tray 3	7	auto

-t Draft mode. Every other pixel is white.**-2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18**

Print in N-up. Requires the **psutils** package.

-o *orient*

Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2hp** for a particular printer.

-u *xoffxyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-l *xoffxyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-L *mask*

Send the logical clipping values from -u/-l in the ZjStream. **foo2hp2600-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

-P

Do not send START_PLANE codes on monochrome output. May be needed by some monochrome-only printers, such as the HP LaserJet 1000.

-X *padlen*

Add extra zero padding to the end of BID segments. The default is 16 bytes. Padding 16 bytes of zeroes is needed for older ZjStream printers, such as the Minolta 2200DL and HP LaserJet 1000, and seems harmless to newer ones, such as the Minolta 2300DL. So the default should be good for all cases.

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as -g“-dDITHERPPI=nnn”, etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. If *profile.icm* is none.icm, then prepare for ordering a ICM custom printer profile (i.e. from www.ICCFactory.com).

-G *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
{0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2hp** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2hp2600-wrapper testpage.ps > testpage.zm
zjsdecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color ZjStream stream from a Postscript document:

```
foo2hp2600-wrapper -c testpage.ps > testpage.zc
```

FILES

/usr/bin/foo2hp2600-wrapper

SEE ALSO

foo2hp(1), **zjsdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2hp.rkkda.com/>

NAME

foo2hp – Convert Ghostscript pbmraw or bitcmk format into a ZJS printer stream

SYNOPSIS

foo2hp [*options*] <*pbmraw-file*> *zjs-file*

foo2hp [*options*] <*bitcmk-file*> *zjs-file*

foo2hp [*options*] <*cups-file*> *zjs-file*

DESCRIPTION

foo2hp converts Ghostscript pbmraw, bitcmk, or cups output formats to monochrome or color ZJS streams, for driving the Hewlett-Packard 2600n color laser printer and other Zenographics-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-b *bits* Bits per plane if autodetect doesn't work (1 or 2) [1].

-c Force color mode if autodetect doesn't work.

-d *duplex*

Duplex code to send to printer [1].

| 1 off | 2 long edge | 3 short edge

-g *xpixxypix*

Set page dimensions in pixels [10200x6600].

-m *media*

Media code to send to printer [1].

Media	HPLJ 2600n
plain	1
preprinted	514
letterhead	513
transparency	2
prepunched	515
labels	265
bond	260
recycled	516
color	512
tough	276
envelope	267
light	258
heavy	262
cardstock	261
lightglossy	268
glossy	269
heavyglossy	270
cover	277
photo	278

-p *paper*

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5jis
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [600x600].

-s *source*

Source (InputSlot) code to send to printer [7].

1	tray 2	7	auto
2	tray 1		

-t Draft mode. Every other pixel is white.**-J** *filename*

Filename string to send to printer.

-U *username*

Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2hp** for a particular printer.

-u *xoffxyoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].

-l *xoffxyoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].

-L *mask*

Send logical clipping amounts implied by -u/-l in the ZjStream [3].

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

-P Do not send START_PLANE codes on monochrome output. May be needed by some black and white only printers, such as the HP LaserJet 1000.**-A** AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmk input only.**-B** BlackClears: K=1 forces C,M,Y to 0. Works with bitcmk input only.**-X** *padlen*

Add extra zero padding to the end of BID segments. The default is 16 bytes.

Debugging Options

These options are used for debugging **foo2hp**.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan

- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a black and white ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r600x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zm
```

Create a color ZJS stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -g5100x6600 -r600x600 -sDEVICE=bitcmyk
-sOutputFile=- - < testpage.ps
| foo2hp -r600x600 -g5100x6600 -p1 >testpage.zc
```

FILES

/usr/bin/foo2hp

SEE ALSO

foo2hp2600-wrapper(1), **zjsdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2hp.rkkda.com/>

NAME

foo2xqx-wrapper – Convert Postscript into a XQX printer stream

SYNOPSIS

foo2xqx-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2xqx-wrapper is a Foomatic compatible printer wrapper for the **foo2xqx** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to XQX printer format for driving the HP LaserJet M1005 MFP and other XQX-based printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-d duplex

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-m media

Media code to send to printer [1].

Media	M1005
standard	1
transparency	2
envelope	257
letterhead	259
thick	261
postcard	262
labels	263

-p paper

Paper size code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n copies

Number of copies [1].

-r xresxyres

Set device resolution in pixels/inch [1200x600].

-s source

Source (Input Slot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

- t** Draft mode. Every other pixel is white.
- 2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18**
Print in N-up. Requires the **psutils** package.
- o orient**
Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2xqx** for a particular printer.

- u xoff yoff**
Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- l xoff yoff**
Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.
- L mask**
Send the logical clipping values from -u/-l in the ZjStream. **foo2xqx-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts

Debugging Options

These options are used for debugging **foo2xqx** and its wrapper.

- D level**
Set Debug level [0].

EXAMPLES

Create a monochrome ZjStream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2xqx-wrapper testpage.ps > testpage.xqx
xqxdecode < testpage.xqx
lpr -P raw testpage.xqx
```

FILES

/usr/bin/foo2xqx-wrapper

SEE ALSO

foo2xqx(1), **xqxdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2xqx.rkkda.com/>

NAME

foo2xqx – Convert Ghostscript pbmraw into a XQX printer stream

SYNOPSIS

foo2xqx [*options*] <*pbmraw-file*> *xqx-file*

DESCRIPTION

foo2xqx converts Ghostscript pbmraw to monochrome XQX streams, for driving the HP LaserJet M1005 MFP and other XQX-based printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-d duplex

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-g xpixxypix

Set page dimensions in pixels [10200x6600].

-m media

Media code to send to printer [1].

Media	M1005
standard	1
transparency	2
envelope	257
letterhead	259
thick	261
postcard	262
labels	263

-p paper

Paper code to send to printer [1].

1	letter	9	A4
5	legal	11	A5
7	executive	13	B5
20	env #10	27	env DL
28	env C5	34	env B5
37	env Monarch		

-n copies

Number of copies [1].

-r xresxyres

Set device resolution in pixels/inch [1200x600].

-s source

Source (InputSlot) code to send to printer [7].

1	upper	4	manual
2	lower	7	auto

-t Draft mode. Every other pixel is white.

- J** *filename*
Filename string to send to printer.
- U** *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2xqx** for a particular printer.

- u** *xoff* *xyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].
- l** *xoff* *xyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].
- L** *mask*
Send logical clipping amounts implied by -u/-l in the ZjStream [3].
 - 0 don't send any logical clipping amounts
 - 1 only send Y clipping amount
 - 2 only send X clipping amount
 - 3 send both X and Y clipping amounts
- A** AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmlyk input only.
- B** BlackClears: K=1 forces C,M,Y to 0. Works with bitcmlyk input only.

Debugging Options

These options are used for debugging **foo2xqx**.

- S** *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.
 - 1 Cyan
 - 2 Magenta
 - 3 Yellow
 - 4 Black
- D** *level*
Set Debug level [0].

EXAMPLES

Create a black and white XQX stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r1200x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2xqx -r1200x600 -g10200x6600 -p1 >testpage.zm
```

FILES

/usr/bin/foo2xqx

SEE ALSO

foo2xqx-wrapper(1), **xqxdecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2xqx.rkkda.com/>

NAME

xqxdecode – Decode a XQX stream into human readable form.

SYNOPSIS

xqxdecode [*options*] <*zjs-file*

DESCRIPTION

xqxdecode decodes a XQX stream into human readable form.

An XQX stream is the printer language used by some HP LaserJet printers, such as the HP LaserJet M1005 (MFP).

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

-d *basename*

Basename of .pbm file for saving decompressed planes.

-h Print hex file offsets.

-o Print file offsets.

-D *level*

 Set Debug level [0].

EXAMPLES

Decode an XQX stream file created by foo2xqx.

```
$ xqxdecode -h < testpage.xm
0: \033%-12345X@PJL JOB
12: @PJL SET JAMRECOVERY=OFF
2b: @PJL SET DENSITY=3
3e: @PJL SET ECONOMODE=OFF
55: @PJL SET RET=MEDIUM
69: @PJL INFO STATUS
7a: @PJL USTATUS DEVICE = ON
93: @PJL USTATUS JOB = ON
a9: @PJL USTATUS PAGE = ON
c0: @PJL USTATUS TIMED = 30
10c: @PJL SET JOBATTR="JobAttr4=20061118160242"
10c: XQX_MAGIC, 0x5851582c (,XQX)
110: XQX_START_DOC(1), 7 items
118:           XQX_0x80000000, 84 (0x54)
124:           XQX_0x10000005, 1 (0x1)
130:           XQX_0x10000001, 0 (0x0)
13c:           XQXI_DMDUPLEX, 0 (0x0)
148:           XQX_0x10000000, 0 (0x0)
154:           XQX_0x10000003, 1 (0x1)
160:           XQXI_END, 3735928559 (0xdeadbeef)
16c: XQX_START_PAGE(3), 15 items [Page 1]
174:           XQX_0x80000000, 180 (0xb4)
180:           XQX_0x20000005, 1 (0x1)
18c:           XQXI_DMDEFAULTSOURCE, 7 (0x7)
198:           XQXI_DMEDIATYPE, 1 (0x1)
1a4:           XQX_0x20000007, 1 (0x1)
1b0:           XQXI_RESOLUTION_X, 600 (0x258)
```

```

1bc:      XQXI_RESOLUTION_Y, 600 (0x258)
1c8:      XQXI_RASTER_X, 9856 (0x2680)
1d4:      XQXI_RASTER_Y, 6432 (0x1920)
1e0:      XQXI_VIDEO_BPP, 2 (0x2)
1ec:      XQXI_VIDEO_X, 4923 (0x133b)
1f8:      XQXI_VIDEO_Y, 6432 (0x1920)
204:      XQXI_ECONOMODE, 0 (0x0)
210:      XQX_0x20000001, 1 (0x1)
21c:      XQXI_END, 3735928559 (0xdeadbeef)
228: XQX_START_PLANE(5), 4 items
230:      XQX_0x80000000, 64 (0x40)
23c:      XQX_0x40000000, 0 (0x0)
248:      XQXI_BIH(0x40000002)
          DL = 0, D = 0, P = 1, - = 0, XY = 9856 x 6432
          L0 = 128, MX = 16, MY = 0
          Order    = 3  ILEAVE SMID
          Options = 92  LRLTWO TPDON TPBON DPON
          51 stripes, 0 layers, 1 planes

264:      XQXI_END, 3735928559 (0xdeadbeef)
270: XQX_JBIG(7), 110 items
2e6: XQX_END_PLANE(6), 0 items
2ee: XQX_END_PAGE(4), 0 items
2f6: XQX_END_DOC(2), 0 items
Total size: 110 bytes
  0: \033%-12345X@PJL EOJ
 12: \033%-12345X

```

FILES

/usr/bin/xqxdecode

SEE ALSO

foo2xqx-wrapper(1), foo2xqx(1)

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2xqx.rkkda.com/>

NAME

foo2lava-wrapper – Convert Postscript into a LAVAFLOW printer stream

SYNOPSIS

foo2lava-wrapper [*options*] [*ps-file*]

DESCRIPTION

foo2lava-wrapper is a Foomatic compatible printer wrapper for the **foo2lava** printer driver. This script reads a Postscript *ps-file* or standard input and converts it to Zenographics LAVAFLOW printer format for driving the Konica Minolta magicolor 2530 DL network color laser printer and other Zenographics-based LAVAFLOW printers.

This script can be used in a standalone fashion, but is intended to be called from a printer spooler system which uses the Foomatic printer database.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Print in color (else monochrome).

-C *colormode*

Color correction mode [0].

- 0 Best compromise
- 1 Photos (using m2300w CRDs)
- 2 Photos and text (using m2300w CRDs)
- 3 Graphics and text (using m2300w CRDs)
- 10 ICM color profile (using -G *.icm file)

-d *duplex*

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-m *media*

Media code to send to printer [0].

Media	2530DL
plain	0
transparency	4
thick stock	20
envelope	22
letterhead	23
postcard	25
labels	26
recycled	27

-p *paper*

Paper size code to send to printer [2].

1	executive	25	A5
2	letter	26	A4
3	legal	45	B5jis
80	env Monarch	65	B5iso
81	env #10	90	env DL

91	env C5	92	env B5
835	4x6" photo	837	10x15cm photo

-n *copies*

Number of copies [1].

-r *xresxyres*

Set device resolution in pixels/inch [1200x600].

-s *source*

Source (Input Slot) code to send to printer [255].

1	Tray 1	255	auto
4	Tray 2		

-t Draft mode. Every other pixel is white.**-2 -3 -4 -5 -6 -8 -9 -10 -12 -14 -15 -16 -18**

Print in N-up. Requires the **psutils** package.

-o *orient*

Orientation used for N-up.

Portrait	-op	(normal)
Landscape	-ol	(rotated 90 degrees anticlockwise)
Seascape	-os	(rotated 90 degrees clockwise)

Printer Tweaking Options

These are the options used to customize the operation of **foo2lava** for a particular printer.

-u *xoff yoff*

Set the offset of the start of the printable region from the upper left corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-l *xoff yoff*

Set the offset of the end of the printable region from the lower right corner, in pixels [varies with paper size]. The defaults should work on the 2200DL and 2300DL, and have not been tested on any other printers.

-L *mask*

Send the logical clipping values from -u/-l in the LAVAFLow stream. **foo2lava-wrapper** always runs Ghostscript with the ideal page dimensions, so that the scale of the image is correct, regardless whether or not the printer has unprintable regions. This option is used to move the position of the clipped image back to where it belongs on the page. The default is to send the amount which was clipped by -u and -l, and should be good in most cases.

- 0 don't send any logical clipping amounts
- 1 only send Y clipping amount
- 2 only send X clipping amount
- 3 send both X and Y clipping amounts

-z *model*

Model: 0=2530DL. Default is 0.

Color Tweaking Options

These are the options used to control the quality of color output. Color correction is currently a WORK IN PROGRESS.

-g *gsopts*

Additional options to pass to Ghostscript, such as -g"-dDITHERPPI=nnn", etc. This option may appear more than once.

-G *profile.icm*

Convert *profile.icm* to a Postscript color rendering dictionary (CRD) using **foo2zjs-icc2ps** and adjust the printer colors by using the Postscript **setcolorrendering** operator. (WORK IN PROGRESS).

-G *gamma-file.ps*

Prepend *gamma-file.ps* to the Postscript input to perform color correction using the **setcolortransfer** Postscript operator. For example, the file might contain:
 {0.333 exp} {0.333 exp} {0.333 exp} {0.333 exp} setcolortransfer

-I *intent*

Select profile intent from the ICM file. 0=Perceptual, 1=Colorimetric, 2=Saturation, 3=Absolute. Default is 0 (perceptual).

Debugging Options

These options are used for debugging **foo2lava** and its wrapper.

-S *plane*

Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

- 1 Cyan
- 2 Magenta
- 3 Yellow
- 4 Black

-D *level*

Set Debug level [0].

EXAMPLES

Create a monochrome LAVAFLOW stream from a Postscript document, examine it, and then print it using a RAW print queue:

```
foo2lava-wrapper testpage.ps > testpage.zm
lavadecode < testpage.zm
lpr -P raw testpage.zm
```

Create a color LAVAFLOW stream from a Postscript document:

```
foo2lava-wrapper -c testpage.ps > testpage.zc
```

FILES

/usr/bin/foo2lava-wrapper

SEE ALSO

foo2lava(1), **lavadecode(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2zjs.rkkda.com/>

NAME

foo2lava – Convert Ghostscript pbmraw or bitcmk format into a LAVAFLOW printer stream

SYNOPSIS

foo2lava [*options*] <*pbmraw-file*> *lava-file*

foo2lava [*options*] <*bitcmk-file*> *lava-file*

foo2lava [*options*] <*pksmraw-file*> *lava-file*

DESCRIPTION

foo2lava converts Ghostscript pbmraw, bitcmk, or pksmraw output formats to monochrome or color LAVAFLOW streams, for driving the Konica Minolta magicolor 2530 DL network color laser printer and other Zenographics-based LAVAFLOW printers.

COMMAND LINE OPTIONS**Normal Options**

These are the options used to select the parameters of a print job that are usually controlled on a per job basis.

-c Force color mode if autodetect doesn't work.

-d duplex

Duplex code to send to printer [1].

1	off	2	long edge	3	short edge
---	-----	---	-----------	---	------------

-g xpixxypix

Set page dimensions in pixels [10200x6600].

-m media

Media code to send to printer [0].

Media	2530DL
plain	0
transparency	4
thick stock	20
envelope	22
letterhead	23
postcard	25
labels	26
recycled	27

-p paper

Paper code to send to printer [2].

1	executive	25	A5
2	letter	26	A4
3	legal	45	B5jis
80	env Monarch	65	B5iso
81	env #10	90	env DL
91	env C5	92	env C6
835	4x6" photo	837	10x15cm photo

-n copies

Number of copies [1].

- r** *xresxyres*
Set device resolution in pixels/inch [1200x600].
- s** *source*
Source (InputSlot) code to send to printer [255].

1	Tray 1	255	auto
4	Tray 2		
- t** Draft mode. Every other pixel is white.
- J** *filename*
Filename string to send to printer.
- U** *username*
Username string to send to printer.

Printer Tweaking Options

These are the options used to customize the operation of **foo2lava** for a particular printer.

- u** *xoffxyoff*
Set the offset of the start of the printable region from the upper left corner, in pixels [0x0].
- l** *xoffxyoff*
Set the offset of the end of the printable region from the lower right corner, in pixels [0x0].
- L** *mask*
Send logical clipping amounts implied by -u/-l in the LAVAFLow stream [3].

0	don't send any logical clipping amounts
1	only send Y clipping amount
2	only send X clipping amount
3	send both X and Y clipping amounts
- A** AllIsBlack: convert C=1,M=1,Y=1 to just K=1. Works with bitcmYk input only.
- B** BlackClears: K=1 forces C,M,Y to 0. Works with bitcmYk input only.
- z** *model*
Model: 0=2530DL. Default is 0.

Debugging Options

These options are used for debugging **foo2lava**.

- S** *plane*
Output just a single color plane from a color print and print it on the black plane. The default is to output all color planes.

1	Cyan
2	Magenta
3	Yellow
4	Black
- D** *level*
Set Debug level [0].

EXAMPLES

Create a black and white LAVAFLow stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE
-sPAPERSIZE=letter -r1200x600 -sDEVICE=pbmraw
-sOutputFile=- - < testpage.ps
| foo2lava -r1200x600 -g10200x6600 -p1 >testpage.zm
```

Create a color LAVAFLow stream:

```
gs -q -dBATCH -dSAFER -dQUIET -dNOPAUSE  
-sPAPERSIZE=letter -g10200x6600 -r1200x600 -sDEVICE=bitcmk  
-sOutputFile=- - < testpage.ps  
| foo2lava -r1200x600 -g10200x6600 -p1 >testpage.zc
```

FILES

/usr/bin/foo2lava

SEE ALSO

foo2lava-wrapper(1), lavadecode(1)

AUTHOR

Rick Richardson <rick.richardson@comcast.com>
<http://foo2zjs.rkkda.com/>

NAME

lavadecode – Decode a XQX stream into human readable form.

SYNOPSIS

lavadecode [*options*] <*zjs-file*

DESCRIPTION

lavadecode decodes a LAVAFLow stream into human readable form.

A LAVAFLow stream is the printer language used by some Konica Minolta printers, such as the KM magicolor 2530 DL.

COMMAND LINE OPTIONS

These are the options that can appear on the command line.

-d *basename*

Basename of .pbm file for saving decompressed planes.

-h Print hex file offsets.

-o Print file offsets.

-D *level*

 Set Debug level [0].

EXAMPLES

Decode an LAVAFLow stream file created by foo2lava.

```
$ lavadecode -h < testpage.prn
0: \033%-12345X@PJL JOB NAME="stdin"
1f: \033%-12345X@PJL JOB USERNAME=" "
3d: \033%-12345X@PJL JOB TIMESTAMP="12/12/2006"
66: \033%-12345X@PJL JOB OSINFO="Linux/2.6.17-1.2187_FC5"
99: \033%-12345X@PJL ENTER LANGUAGE=LAVAFLow
bf: \033E                      RESET
c1: \033&l0S                    DUPLEX
c6: \033&l0G
cb: \033&u1200D                  X RESOLUTION
d3: \033&l1X                     COPIES
d8: \033&x1X                     TRANSMIT ONCE COPIES
dd: \033&l0O                     ORIENTATION
e2: \033*r1U                     NBIE
e7: \033*g8W                     BW/COLOR
ec: \033*b1234M                  COMPRESSION
f4: \033&l2A                     PAGE SIZE
f9: \033&l255H                   PAPER SOURCE
100: \033&l0M                    MEDIA TYPE
105: \033&l0E                    TOP MARGIN
10a: \033*r9820S                 X RASTER
112: \033*r6410T                 Y RASTER
11a: \033&l0U
11f: \033&l0Z
124: \033*p200X                  X OFFSET
12b: \033*p200Y                  Y OFFSET
132: \033*r1A                    [Page 1]
137: \033*b20V                   [black]
```

```
DL = 0, D = 0, P = 1, - = 0, XY = 9820 x 6410
L0 = 128, MX = 16, MY = 0
Order   = 3   ILEAVE SMID
Options = 92   LRLTWO TPDON TPBON DPON
51 stripes, 0 layers, 1 planes
```

```
151: \033*b65536W      JBIG data (cont)
1015a: \033*b27374W    JBIG data (cont)
16c51: \033*r0C        END PAGE
16c56: \033E           RESET
16c58: \033%-12345X
```

FILES

/usr/bin/lavadecode

SEE ALSO

foo2lava-wrapper(1), **foo2lava(1)**

AUTHOR

Rick Richardson <rick.richardson@comcast.net>
<http://foo2xqx.rkkda.com/>

